Tier 4 Final Engine

Net Power SAE J1349 / 270 HP (202 kW) at 1,800 rpm Bucket Range 1.88 yd³ - 2.75 yd³ Standard Bucket 1.44 m³ (1.88 yd³) Operating Weight 35,050 kg / 77,270 lb

ENGINE					
Make / Model		Cummins QSL9			
Туре		4-cycle turbocharged, charge air-cooled, diesel engine			
Rated	J1995 (gross)	284 HP (212 kW) at 1,800 rpm			
flywheel SAE horsepower	J1349 (net)	270 HP (202 kW) at 1,800 rpm			
Max. torque		123.7 kgf·m (895 lbf·ft) at 1500 rpm			
Bore X stroke		114 × 145 mm (4.49"×5.69")			
Piston displacement		8,900 cc (543 in³)			
Batteries		2 × 12 V × 160 Ah			
Starting motor		24 V - 7.8 kW			
Alternator		24 V - 95 Amp			

	INAD		
DIKVAL		YSIE	W

IVIAIN PUIVIP	
Туре	Variable-displacement piston pumps
Max. flow	2 × 277.2 l/min (73.2 gpm)
Sub-pump for pilot circuit (Gear Pump)	26.3 l/min (6.9 gpm)

CROSS-SENSING AND FUEL-S	AVING PUMP SYSTEM			
HYDRAULIC MOTORS				
Travel Two speed axial piston motor				
Swing	Axial piston motor			
RELIEF VALVE SETTING				
Implement circuits	400 kgf/cm² (5,690 psi)			
Travel	350 kgf/cm² (4,980 psi)			
Power boost (boom, arm, bucket)	380 kgf/cm² (5,400 psi)			
Swing circuit	300 kgf/cm² (4,270 psi)			
Pilot circuit	40 kgf/cm² (569 psi)			
Service valve	Installed			
HYDRAULIC CYLINDERS				
No. of milindons	Boom: 150 x 1,480 mm (5.9 x 58.3")			
No. of cylinders bore X stroke	Arm: 160 x 1,685 mm (6.3 × 66.3")			
DOIC / SHOKE	D 1 : 440 4 305 /F F F0 6(1)			

DRIVES & BRAKES	
Drive method	Fully hydrostatic type
Drive motor	Axial piston motor, in-shoe design
Reduction system	Planetary reduction gear
Max. drawbar pull	27,000 kgf (59,500 lbf)
Max. travel speed (high / low)	5.9 km/hr (3.67 mph) 3.4 km/hr (2.11 mph)
Gradeability	35° (70%)
Parking brake	Multi wet disc brake

Bucket: 140 x 1,285 mm (5.5 × 50.6")

CONTROL

Pilot pressure operated joysticks and pedals with detachable lever for minimal operator fatigue.

Pilot control	Two joysticks with one safety lever (LH): Swing and arm (RH): Boom and bucket (ISO)
Traveling and steering	Two levers with pedals
Engine throttle	Electric, dial type



OPERATING WEIGHT (APPROXIMATE)

Operating weight, including 6,450 mm (21' 2") boom, 3,200 mm (10' 6") arm, SAE heaped 1.44 m 3 (1.88 yd 3) bucket, lubricant, coolant, full fuel tank, full hydraulic tank, 6,600 kg (14,550 lb) counterweight and all standard equipment.

OPERATING WEIGHT

Width		Ope	rating weight	Ground pressure	
		kg (lb)	kgf/cm² (psi)		
T: 1	700 (28")	HX330L	34,670 (76,430)	0.57 (8.11)	
Triple grouser	800 (32")	HX330L	35,050 (77,270)	0.51 (7.25)	
grouser	900 (36")	HX330L	35,430 (78,110)	0.46 (6.54)	

SWING SYSTEM		
Swing motor	Fixed displacement axial piston motor	
Swing reduction	Planetary reduction gear	
Swing bearing lubrication	Grease-bathed	
Swing brake	Multi wet disc brake	
Swing speed	9.1 rpm	

SERVICE REFILL CAPACITIES					
Refilling	liters	US gal			
Fuel tank	600	154.7			
Engine coolant	55	14.5			
Engine oil	30	7.9			
Swing device	11	2.91			
Final drive (each)	7.8	2.06			
Hydraulic system (including tank)	330	87.2			
Hydraulic tank	210	55.5			
DEF/AdBlue®	42.5	11.2			

UNDERCARRIAGE

The X-leg type center frame is integrally welded with reinforced box-section track frames. The undercarriage includes lubricated rollers, idlers, track adjusters with shock-absorbing springs and sprockets, and a track chain with double or triple grouser shoes.

Center frame	X - leg type		
Track frame	Pentagonal box type		
No. of shoes on each side	48 EA		
No. of carrier roller on each side	2 EA		
No. of track roller on each side	9 EA		
No. of rail guard on each side	2 EA		


Tier 4 Final Engine

HX330L DIMENSIONS

Unit: mm (ft·in)


6.45 m (21' 2"), 6.15 m (20' 2") boom and 2.2 m (7' 3"), 2.5 m (8' 2"), 3.2 m (10' 6"), 4.05 m (13' 3") arm

Α	Tumbler distance	4,030 (13' 3")
В	Overall length of crawler	4,940 (16' 2")
C	Ground clearance of counterweight	1,200 (3' 11")
D	Tail-swing radius	3,570 (11' 7")
D'	Rear-end length	3,505 (11' 5")
Е	Overall width of upper structure	2,980 (9' 9")
F	Overall height of cab	3,160 (10' 4")
G	Min. ground clearance	500 (1' 8")
Н	Track gauge	2,680 (8' 10")
1	Overall height of guardrail	3,350 (11' 0")



	Boom length	6,150 (20' 2")	6,450 (21' 2")			
	Arm length	2,200 (7' 3")	2,200 (7' 3")	2,500 (8' 2")	3,200 (10' 6")	4,050 (13' 3")
J	Overall length	11,170 (36' 8")	11,470 (37' 8")	11,340 (37' 2")	11,220 (36' 10")	11,220 (36' 10")
K	Overall height of boom	3,680 (12' 1")	3,740 (11' 11")	3,760 (12' 0")	3,380 (11' 1")	3,860 (12' 8")
L	Track shoe width	600 (24")	700 (2	8") 8	300 (32")	900 (36")
М	Overall width	3,280 (10' 9")	3,38 (11' 1		3,480 (11' 5")	3,580 (11' 5")


HX330L WORKING	G RANGE				Unit : mm (ft·in)				
Boom length	6,150 (20' 2")		6,450 (21' 2")						
Arm length	2,200	2,200	2,500	3,200	4,050				
	(7' 3")	(7' 3")	(8' 2")	(10' 6")	(13' 3")				
A Max. digging reach	10,020	10,330	10,550	11,140	11,950				
	(32' 10")	(33' 11")	(34' 7")	(36' 7")	(39' 2")				
A' Max. digging reach on ground	9,800	10,110	10,330	10,940	11,760				
	(32' 2")	(33' 2")	(33' 11")	(35' 11")	(38' 7")				
B Max. digging depth	6,160	6,370	6,670	7,370	8,220				
	(20' 3")	(20' 11")	(21' 11")	(24' 2")	(26' 12")				
B' Max. digging depth (8' level)	5,950	6,160	6,470	7,210	8,080				
	(19' 6")	(20' 3")	(21' 3")	(23' 8")	(26' 6")				
C Max. vertical wall digging depth	5,710	5,980	5,920	6,360	7,260				
	(18' 9")	(19' 7")	(19' 5")	(20' 10")	(23' 10")				
D Max. digging height	9,940	10,220	10,170	10,310	10,710				
	(32' 7")	(33' 6")	(33' 4")	(33' 10")	(35' 2")				
E Max. dumping height	6,780	7,050	7,050	7,240	7,630				
	(22' 3")	(23' 2")	(23' 2")	(23' 9")	(25' 0")				
F Min. swing radius	4,520	4,700	4,550	4,460	4,470				
	(14' 10")	(15' 5")	(14' 11")	(14' 8")	(14' 8")				



DIGGING FOR	RCE								
Length mm		mm (ft·in)	6,150 (20' 2")	6,450 (21' 2")					
Boom	Weight	kg (lb)	2,950 (6,500)	3,030 (6,680)					
Arm	Length	mm (ft·in)	2,200 (7' 3")	2,200 (7' 3")	2,500 (8' 2")	3,200 (10' 6")	4,050 (13' 3")		
Arm	Weight	kg (lb)	1,560 (3,440)	1,560 (3,440)	1,650 (3,640)	1,770 (3,900)	1,870 (4,120)		
		kN	189.3 [205.5]	189.3 [205.5]	189.3 [205.5]	189.3 [205.5]	189.3 [205.5]		
		kgf	19,300 [20,950]	19,300 [20,950]	19,300 [20,950]	19,300 [20,950]	19,300 [20,950]		
Bucket		lbf	42,550 [46,200]	42,550 [46,200]	42,550 [46,200]	42,550 [46,200]	42,550 [46,200]		
digging – force	ISO		kN	211.8 [230.0]	211.8 [230.0]	211.8 [230.0]	211.8 [230.0]	211.8 [230.0]	[Power
		kgf	21,600 [23,450]	21,600 [23,450]	21,600 [23,450]	21,600 [23,450]	21,600 [23,450]	Boost]	
		lbf	47,620 [51,700]	47,620 [51,700]	47,620 [51,700]	47,620 [51,700]	47,620 [51,700]		
	SAE Arm	kN	196.6 [213.4]	196.6 [213.4]	178.9 [194.2]	143.2 [155.5]	119.6 [129.9]		
Arm crowd force		kgf	20,000 [21,760]	20,000 [21,760]	18,200 [19,810]	14,600 [15,850]	12,200 [13,240]		
		lbf	44,190 [47,980]	44,190 [47,980]	40,220 [43,670]	32,190 [34,950]	26,890 [29,190]		
	ISO	kN	202.8 [220.2]	202.8 [220.2]	185.1 [201.0]	147.1 [159.7]	122.7 [133.3]		
		kgf	20,700 [22,450]	20,700 [22,450]	18,900 [20,500]	15,000 [16,290]	12,515 [13,590]		
		lbf	45,600 [49,510]	45,600 [49,510]	41,620 [45,190]	33,070 [35,900]	27,590 [29,950]		

Note : Boom weight includes arm cylinder, piping, and pin Arm weight includes bucket cylinder, linkage, and pin

Tier 4 Final Engine



Lifting Capacity

Boom: 6.45 m (21' 2") Arm: 3.2 m (10' 6") Capacities based on North American Standard Configuration in accordance with ISO condition 2 standard.

Bucket: 1.44 m³ (1.88 yd³) SAE heaped

Rating over front Rating over front Rating over side or 360 degree

*25,810

(22.1)

17,220

Shoe 800 mm (32") triple grouser, CWT 6,600 kg (14,550 lb)

				<u> </u>												
						Lift-poir	nt radius					A	t max. reach			
Lift-point height m (ft)		3.0 m (9.8 ft)		4.5 m (14.8 ft)		6.0 m (19.7 ft)		7.5 m (24.6 ft)		9.0 m (29.5 ft)		Capacity		Reach		
		P						Į.		P		P		J		
7.5 m	kg							*7,770	7,570			*6,550	*6,550	7.76		
24.6 ft	lb							*17,120	16,690			*14,430	*14,430	(25.5)		
6.0 m	kg							*9,290	7,510			*6,340	5,930	8.63		
19.7 ft	lb							*20,470	16,550			*13,980	13,080	(28.3)		
4.5 m	kg					*11,370	10,260	*10,080	7,300	*7,820	5,460	*6,370	5,290	9.18		
14.8 ft	lb					*25,070	22,610	*22,220	16,090	*17,250	12,050	*14,050	11,660	(30.1)		
3.0 m	kg			*18,340	14,790	*13,420	9,730	10,470	7,030	7,910	5,350	*6,610	4,950	9.45		
9.8 ft	lb			*40,430	32,610	*29,580	21,450	23,070	15,510	17,430	11,790	*14,570	10,920	(31.0)		
1.5 m	kg			*18,340	13,940	14,320	9,270	10,190	6,790	7,770	5,230	*7,070	4,840	9.47		
4.9 ft	lb			*40,440	30,730	31,570	20,440	22,470	14,960	17,130	11,520	*15,580	10,680	(31.1)		
Ground	kg			*19,370	13,590	13,990	8,990	9,990	6,610	7,680	5,140	7,380	4,950	9.25		
Line	lb			*42,710	29,960	30,840	19,810	22,030	14,560	16,930	11,330	16,270	10,910	(30.4)		
-1.5 m	kg	*12,510	*12,510	*22,400	13,540	13,860	8,870	9,910	6,530			7,950	5,310	8.77		
-4.9 ft	lb	*27,590	*27,590	*49,390	29,840	30,560	19,560	21,840	14,390			17,520	11,700	(28.8)		
-3.0 m	kg	*20,130	*20,130	*21,230	13,660	13,910	8,910	9,960	6,580			9,160	6,090	7.97		
-9.8 ft	lb	*44,380	*44,380	*46,800	30,120	30,660	19,650	21,960	14,500			20,180	13,420	(26.2)		
-4.5 m	kg	*25,050	*25,050	*18,390	13,970	*13,830	9,140					*11,710	7,810	6.75		

NOTES:

-14.8 ft | lb

1. Lifting capacities are based on ISO 10567.

*55,220

2. Lifting capacity of the HX Series does not exceed 75% of tipping load with the machine on firm, level ground or 87% of full hydraulic capacity.

*55,220


*40,540

30,800

*30,500

20,140

- 3. The Lift-point is bucket pivot mounting pin on the arm (without bucket mass).
- 4. (*) indicates load limited by hydraulic capacity.



Tier 4 Final Engine

Cummins QSL 9 engine HYDRAULIC SYSTEM Intelligent Power Control (IPC) 3-power mode, 2-work mode, user mode Variable power control Pump flow control Attachment mode flow control Engine auto idle Engine auto slutdown control Engine auto slutdown control CAB & INTERIOR ISO Standard cabin Rise-up type windshield wiper Radio / USB player Bluetooth / hands-free mobile phone system with USB Miracast 12-volt power outlet (24V DC to 12V DC converter) Electric horn All-weather steel cab with 360° visibility Safety glass windows Sliding fold-in front window Sliding fold-in front window Sliding side window (IH) Lockable door Hot and cool box Storage compartment and ashtray Transparent cabin roof cover Sun visor Door and cab locks, one key Mechanical suspension seat with heater Plot-operated adjustable joystick Console box height adjust system Cabin lights Cabin front window rain guard Cabin roof-steel cover Automatic climate control Air conditioner and heater Defroster Starting aid (air grid heater) for cold weather Centralized monitoring 8* LCD display Max. power Low pseed / high speed Auto idle Overload Check engine Air cleaner clogging Indicators ECO gauges Fuel level gauge Hydraulic oil temperature gauge Fuel warmer Warnings Communication error Low battery Clock Communication error	ENGINE	STD	ОРТ
Intelligent Power Control (IPC) 3-power mode, 2-work mode, user mode 4 Ariable power control 9 Pump flow control Attachment mode flow control 4 Engine auto shutdown control Electronic fan control CAB & INTERIOR ISO Standard cabin Rise-up type windshield wiper Radio / USB player Bluetooth / hands-free mobile phone system with USB Miracast 12-volt power outlet (24V DC to 12V DC converter) Electric horn All-weather steel cab with 360° visibility 5Iding side window (LH) 10-ckable door Hot and cool box Storage compartment and ashtray Transparent cabin roof cover Sun visor Door and cab locks, one key Mechanical suspension seat with heater Pilot-operated adjustable joystick Cabin Front window rain guard Cabin roof-steel cover Automatic climate control Air conditioner and heater Formatic climate control Air conditioner and heater Starting aid (air grid heater) for cold weather Centralized monitoring 8* LCD display Engine speed or trip meter / accel. Engine coolant temperature gauge Max. power Low speed / high speed Auto idle Overload Check engine Air cleaner clogging Indicators ECO gauges Fuel level gauge Hydraulic oil temperature gauge Fuel warmer Warnings Communication error Low battery • Communication error Low battery • Communication error Low battery • Communication error Low battery	Cummins QSL 9 engine	•	
3-power mode, 2-work mode, user mode Variable power control Pump flow control Attachment mode flow control Engine auto idle Engine auto shutdown control Electronic fan control CAB & INTERIOR ISO Standard cabin Rise-up type windshield wiper Radio / USB player Bluetooth / hands-free mobile phone system with USB Miracast 12-volt power outlet (24V DC to 12V DC converter) Electric horn All-weather steel cab with 360° visibility Safety glass windows Sliding fold-in front window Sliding fold-in front window Sliding side window (LH) Lockable door Hot and cool box Storage compartment and ashtray Transparent cabin roof cover Sun visor Door and cab locks, one key Mechanical suspension seat with heater Pilot-operated adjustable joystick Console box height adjust system Cabin lights Cabin front window rain guard Cabin roof-steel cover Automatic climate control Altr conditioner and heater Defroster Starting aid (air grid heater) for cold weather Centralized monitoring 8° LCD display Engine speed or trip meter / accel. Engine coolant temperature gauge Max. power Low speed / high speed Auto idle Overload Check engine Air cleaner clogging Indicators ECO gauges Fuel level gauge Hydraulic oil temperature gauge Fuel warmer Warnings Communication error Low battery • Communication error Low battery • Communication error Low battery	HYDRAULIC SYSTEM		
3-power mode, 2-work mode, user mode Variable power control Pump flow control Attachment mode flow control Engine auto idle Engine auto shutdown control Electronic fan control CAB & INTERIOR ISO Standard cabin Rise-up type windshield wiper Radio / USB player Bluetooth / hands-free mobile phone system with USB Miracast 12-volt power outlet (24V DC to 12V DC converter) Electric horn All-weather steel cab with 360° visibility Safety glass windows Sliding fold-in front window Sliding fold-in front window Sliding side window (LH) Lockable door Hot and cool box Storage compartment and ashtray Transparent cabin roof cover Sun visor Door and cab locks, one key Mechanical suspension seat with heater Pilot-operated adjustable joystick Console box height adjust system Cabin lights Cabin front window rain guard Cabin roof-steel cover Automatic climate control Altr conditioner and heater Defroster Starting aid (air grid heater) for cold weather Centralized monitoring 8° LCD display Engine speed or trip meter / accel. Engine coolant temperature gauge Max. power Low speed / high speed Auto idle Overload Check engine Air cleaner clogging Indicators ECO gauges Fuel level gauge Hydraulic oil temperature gauge Fuel warmer Warnings Communication error Low battery • Communication error Low battery • Communication error Low battery	Intelligent Power Control (IPC)		
Variable power control Pump flow control Attachment mode flow control Engine auto idle Engine auto shutdown control Engine auto shutdown control Electronic fan control Electronic fan control Electronic fan control Iso Standard cabin Rise-up type windshield wiper Radio / USB player Bluetooth / hands-free mobile phone system with USB Miracast 12-volt power outlet (24V DC to 12V DC converter) Electric horn All-weather steel cab with 360° visibility Safety glass windows Sliding fold-in front window Sliding side window (LH) Lockable door Hot and cool box Storage compartment and ashtray Transparent cabin roof cover Sun visor Door and cab locks, one key Mechanical suspension seat with heater Pilot-operated adjustable joystick Console box height adjust system Cabin front window arin guard Cabin roof-steel cover Automatic climate control Air conditioner and heater Defroster Starting aid (air grid heater) for cold weather Defroster Starting aid (air grid heater) for cold weather Defroster Starting aid (air grid heater) for cold weather Defroster Starting aid (air grid heater) for cold weather Centralized monitoring 8* LCD display Automatic climate control Air conditioner and heater Defroster Starting aid (air grid heater) for cold weather Centralized monitoring 8* LCD display Automatic climate control Air conditioner and heater Defroster Starting aid (air grid heater) for cold weather Centralized monitoring 8* LCD display Automatic climate control Air conditioner and heater Defroster Starting aid (air grid heater) for cold weather Centralized monitoring 8* LCD display Centralized monitoring 8* LCD display Company and cold temperature gauge Auto idle Overload Check engine Air cleaner clogging Indicators EcC ogauges Fuel level gauge Hydraulic oil temperature gauge Fuel warmer Warnings Communication error Low battery Overload Communication error	9	•	
Pump flow control Attachment mode flow control Engine auto idle Engine auto shutdown control Electronic fan control CAB & INTERIOR ISO Standard cabin Rise-up type windshield wiper Radio / USB player Bluetooth / hands-free mobile phone system with USB Miracast 12-volt power outlet (24V DC to 12V DC converter) Electric horn All-weather steel cab with 360° visibility Safety glass windows Sliding side window (LH) Lockable door Hot and cool box Storage compartment and ashtray Transparent cabin roof cover Sun visor Door and cab locks, one key Mechanical suspension seat with heater Pilot-operated adjustable joystick Console box height adjust system Cabin front window rain guard Cabin roof-steel cover Automatic climate control Air conditioner and heater Defroster Starting aid (air grid heater) for cold weather Defroster Starting aid (air grid heater) for cold weather Defroster Starting aid (air grid heater) for cold weather Centralized monitoring 8° LCD display Engine speed or trip meter / accel. Engine coolant temperature gauge Max. power Low speed / high speed Auto idle Overload Check engine Air cleaner clogging Indicators ECO gauges Fuel level gauge Hydraulic oil temperature gauge Fuel warmer Warnings Communication error Low battery • Communication error Low battery		•	
Attachment mode flow control Engine auto idle Engine auto shutdown control Electronic fan control CAB & INTERIOR ISO Standard cabin Rise-up type windshield wiper Radio / USB player Bluetooth / hands-free mobile phone system with USB Miracast 12-volt power outlet (24V DC to 12V DC converter) Electric horn 12-volt power outlet (24V DC to 12V DC converter) Electric horn 15-did in front window Sliding fold-in front window Sliding side window (LH) Lockable door Hot and cool box Storage compartment and ashtray Transparent cabin roof cover Sun visor Door and cab locks, one key Mechanical suspension seat with heater Pilot-operated adjustable joystick Console box height adjust system Cabin lights Cabin front window rain guard Cabin roof-steel cover Automatic climate control Air conditioner and heater Defroster Starting aid (air grid heater) for cold weather Engine speed or trip meter / accel. Engine coolant temperature gauge Max. power Low speed / high speed Auto idle Overload Check engine Air cleaner clogging Indicators ECO gauges Fuel level gauge Hydraulic oil temperature gauge Fuel warmer Warnings Communication error Low battery • Communication error Low battery • Communication error Low battery	·	•	
Engine auto idle Engine auto shutdown control Electronic fan control CAB & INTERIOR ISO Standard cabin Rise-up type windshield wiper Radio / USB player Bluetooth / hands-free mobile phone system with USB Miracast 12-volt power outlet (24V DC to 12V DC converter) Electric horn All-weather steel cab with 360° visibility Safety glass windows Sliding fold-in front window Sliding side window (LH) Lockable door Hot and cool box Storage compartment and ashtray Transparent cabin roof cover Sun visor Door and cab locks, one key Mechanical suspension seat with heater Pilot-operated adjustable joystick Console box height adjust system Cabin front window rain guard Cabin roof-steel cover Automatic climate control Air conditioner and heater Defroster Starting aid (air grid heater) for cold weather Centralized monitoring 8* LCD display Engine speed or trip meter / accel. Engine coolant temperature gauge Auto idle Overload Check engine Air cleaner clogging Indicators ECO gauges Fuel level gauge Hydraulic oil temperature gauge Fuel warmer Warnings Communication error Low battery		•	
Engine auto shutdown control Electronic fan control CAB & INTERIOR ISO Standard cabin Rise-up type windshield wiper Radio / USB player Bluetooth / hands-free mobile phone system with USB Miracast 12-volt power outlet (24V DC to 12V DC converter) Electric horn All-weather steel cab with 360° visibility Safety glass windows Sliding fold-in front window Sliding side window (LH) Lockable door Hot and cool box Storage compartment and ashtray Transparent cabin roof cover Sun visor Door and cab locks, one key Mechanical suspension seat with heater Pilot-operated adjustable joystick Console box height adjust system Cabin lights Cabin front window rain guard Cabin roof-steel cover Automatic climate control Air conditioner and heater Defroster Starting aid (air grid heater) for cold weather Centralized monitoring 8* LCD display Engine speed or trip meter / accel. Engine coolant temperature gauge Max. power Low speed / high speed Auto idle Overload Check engine Air cleaner clogging Indicators ECO gauges Fuel level gauge Hydraulic oil temperature gauge Fuel level gauge Hydraulic oil temperature gauge Fuel level gauge Hydraulic oil temperature gauge Fuel level gauge Fuel warmer Warnings Communication error Low battery		•	
Electronic fan control CAB & INTERIOR ISO Standard cabin Rise-up type windshield wiper Radio / USB player Bluetooth / hands-free mobile phone system with USB Miracast 12-volt power outlet (24V DC to 12V DC converter) Electric horn All-weather steel cab with 360° visibility after yeas windows Sliding fold-in front window Sliding side window (LH) Lockable door Hot and cool box Storage compartment and ashtray Transparent cabin roof cover Sun visor Door and cab locks, one key Mechanical suspension seat with heater Pilot-operated adjustable joystick Console box height adjust system Cabin lights Cabin front window rain guard Cabin roof-steel cover Automatic climate control Air conditioner and heater Defroster Starting aid (air grid heater) for cold weather Centralized monitoring 8° LCD display Engine speed or trip meter / accel. Engine coolant temperature gauge Max. power Low speed / high speed Auto idle Overload Check engine Air cleaner clogging Indicators ECO gauges Fuel level gauge Hydraulic oil temperature gauge Fuel level gauge Hydraulic oil temperature gauge Fuel level gauge Hydraulic oil temperature gauge Fuel warmer Warnings Communication error Low battery • Communication error Low battery • Communication error Low battery	3		•
Rise-up type windshield wiper Radio / USB player Bluetooth / hands-free mobile phone system with USB Miracast 12-volt power outlet (24V DC to 12V DC converter) Electric horn All-weather steel cab with 360° visibility Safety glass windows Sliding fold-in front window Sliding side window (LH) Lockable door Hot and cool box Storage compartment and ashtray Transparent cabin roof cover Sun visor Door and cab locks, one key Mechanical suspension seat with heater Pilot-operated adjustable joystick Console box height adjust system Cabin lights Cabin front window rain guard Cabin roof-steel cover Automatic climate control Air conditioner and heater Defroster Starting aid (air grid heater) for cold weather Centralized monitoring 8* LCD display Engine speed or trip meter / accel. Engine coolant temperature gauge Max. power Low speed / high speed Auto idle Overload Check engine Air cleaner clogging Indicators ECO gauges Fuel level gauge Hydraulic oil temperature gauge Fuel level gauge Hydraulic oil temperature gauge Fuel level gauge Hydraulic oil temperature gauge Fuel warmer Warnings Communication error Low battery • Communication error Low battery	3	•	
Rise-up type windshield wiper Radio / USB player Bluetooth / hands-free mobile phone system with USB Miracast 12-volt power outlet (24V DC to 12V DC converter) Electric horn All-weather steel cab with 360° visibility Safety glass windows Sliding fold-in front window Sliding side window (LH) Lockable door Hot and cool box Storage compartment and ashtray Transparent cabin roof cover Sun visor Door and cab locks, one key Mechanical suspension seat with heater Pilot-operated adjustable joystick Console box height adjust system Cabin front window rain guard Cabin roof-steel cover Automatic climate control Air conditioner and heater Defroster Starting aid (air grid heater) for cold weather Engine speed or trip meter / accel. Engine coolant temperature gauge Max. power Low speed / high speed Auto idle Overload Check engine Air cleaner clogging Indicators ECO gauges Fuel level gauge Hydraulic oil temperature gauge Fuel warmer Warnings Communication error Low battery • Communication error Low battery	CAB & INTERIOR		
Radio / USB player Bluetooth / hands-free mobile phone system with USB Miracast 12-volt power outlet (24V DC to 12V DC converter) Electric horn All-weather steel cab with 360° visibility Safety glass windows Sliding fold-in front window Sliding side window (LH) Lockable door Hot and cool box Storage compartment and ashtray Transparent cabin roof cover Sun visor Door and cab locks, one key Mechanical suspension seat with heater Pilot-operated adjustable joystick Console box height adjust system Cabin front window rain guard Cabin roof-steel cover Automatic climate control Air conditioner and heater Defroster Starting aid (air grid heater) for cold weather Engine speed or trip meter / accel. Engine coolant temperature gauge Max. power Low speed / high speed Auto idle Overload Check engine Air cleaner clogging Indicators ECO gauges Fuel level gauge Hydraulic oil temperature gauge Fuel warmer Warnings Communication error Low battery • Communication error Low battery	ISO Standard cabin		
Bluetooth / hands-free mobile phone system with USB Miracast 12-volt power outlet (24V DC to 12V DC converter) Electric horn All-weather steel cab with 360° visibility Safety glass windows Sliding fold-in front window Sliding side window (LH) Lockable door Hot and cool box Storage compartment and ashtray Transparent cabin roof cover Sun visor Door and cab locks, one key Mechanical suspension seat with heater Pilot-operated adjustable joystick Console box height adjust system Cabin lights Cabin front window rain guard Cabin roof-steel cover Automatic climate control Air conditioner and heater Defroster Starting aid (air grid heater) for cold weather Engline speed or trip meter / accel. Engine speed or trip meter / accel. Engine speed or trip meter / accel. Engine speed / high speed Auto idle Overload Check engine Air cleaner clogging Indicators ECO gauges Fuel level gauge Hydraulic oil temperature gauge Fuel warmer Warnings Communication error Low bettery	Rise-up type windshield wiper	•	
Miracast 12-volt power outlet (24V DC to 12V DC converter) Electric horn All-weather steel cab with 360° visibility Safety glass windows Sliding fold-in front window Sliding side window (LH) Lockable door Hot and cool box Storage compartment and ashtray Transparent cabin roof cover Sun visor Door and cab locks, one key Mechanical suspension seat with heater Pilot-operated adjustable joystick Console box height adjust system Cabin lights Cabin front window rain guard Cabin roof-steel cover Automatic climate control Air conditioner and heater Defroster Starting aid (air grid heater) for cold weather Centralized monitoring 8" LCD display Engine speed or trip meter / accel. Engine coolant temperature gauge Max. power Low speed / high speed Auto idle Overload Check engine Air cleaner clogging Indicators ECO gauges Fuel level gauge Hydraulic oil temperature gauge Fuel level marmer Warnings Communication error Low battery	Radio / USB player	•	
12-volt power outlet (24V DC to 12V DC converter) Electric horn All-weather steel cab with 360° visibility • Safety glass windows Sliding fold-in front window Sliding side window (LH) Lockable door Hot and cool box Storage compartment and ashtray Transparent cabin roof cover Sun visor Door and cab locks, one key Mechanical suspension seat with heater Pilot-operated adjustable joystick Cabin lights Cabin front window rain guard Cabin roof-steel cover Automatic climate control Air conditioner and heater Defroster Starting aid (air grid heater) for cold weather Centralized monitoring 8* LCD display Engine speed or trip meter / accel. Engine coolant temperature gauge Max. power Low speed / high speed Auto idle Overload Check engine Air cleaner clogging Indicators ECO gauges Fuel level gauge Hydraulic oil temperature gauge Fuel level gauge Fuel level gauge Hydraulic oil temperature gauge Communication error Low battery • Communication error Low battery	Bluetooth / hands-free mobile phone system with USB	•	
Electric horn All-weather steel cab with 360° visibility Safety glass windows Sliding fold-in front window Sliding side window (LH) Lockable door Hot and cool box Storage compartment and ashtray Transparent cabin roof cover Sun visor Door and cab locks, one key Mechanical suspension seat with heater Pilot-operated adjustable joystick Console box height adjust system Cabin lights Cabin front window rain guard Cabin roof-steel cover Automatic climate control Air conditioner and heater Defroster Starting aid (air grid heater) for cold weather Centralized monitoring 8° LCD display Engine speed or trip meter / accel. Engine coolant temperature gauge Max. power Low speed / high speed Auto idle Overload Check engine Air cleaner clogging Indicators ECO gauges Fuel level gauge Hydraulic oil temperature gauge Fuel level gauge Hydraulic oil temperature gauge Fuel level gauge Hydraulic oil temperature gauge Fuel level gauge Fuel warmer Warnings Communication error Low battery	Miracast		
All-weather steel cab with 360° visibility Safety glass windows Sliding fold-in front window Sliding side window (LH) Lockable door Hot and cool box Storage compartment and ashtray Transparent cabin roof cover Sun visor Door and cab locks, one key Mechanical suspension seat with heater Pilot-operated adjustable joystick Console box height adjust system Cabin lights Cabin front window rain guard Cabin roof-steel cover Automatic climate control Air conditioner and heater Defroster Starting aid (air grid heater) for cold weather Centralized monitoring 8* LCD display Engine speed or trip meter / accel. Engine coolant temperature gauge Max. power Low speed / high speed Auto idle Overload Check engine Air cleaner clogging Indicators ECO gauges Fuel level gauge Hydraulic oil temperature gauge Fuel warmer Warnings Communication error Low battery	12-volt power outlet (24V DC to 12V DC converter)	•	
Safety glass windows Sliding fold-in front window Sliding side window (LH) Lockable door Hot and cool box Storage compartment and ashtray Transparent cabin roof cover Sun visor Door and cab locks, one key Mechanical suspension seat with heater Pilot-operated adjustable joystick Console box height adjust system Cabin lights Cabin front window rain guard Cabin roof-steel cover Automatic climate control Air conditioner and heater Defroster Starting aid (air grid heater) for cold weather Centralized monitoring 8" LCD display Engine speed or trip meter / accel. Engine coolant temperature gauge Max. power Low speed / high speed Auto idle Overload Check engine Air cleaner clogging Indicators FCO gauges Fuel level gauge Hydraulic oil temperature gauge Fuel warmer Warnings Communication error Low battery • Communication error Low battery • Communication error	Electric horn	•	
Safety glass windows Sliding fold-in front window Sliding side window (LH) Lockable door Hot and cool box Storage compartment and ashtray Transparent cabin roof cover Sun visor Door and cab locks, one key Mechanical suspension seat with heater Pilot-operated adjustable joystick Console box height adjust system Cabin lights Cabin front window rain guard Cabin roof-steel cover Automatic climate control Air conditioner and heater Defroster Starting aid (air grid heater) for cold weather Centralized monitoring 8" LCD display Engine speed or trip meter / accel. Engine coolant temperature gauge Max. power Low speed / high speed Auto idle Overload Check engine Air cleaner clogging Indicators FCO gauges Fuel level gauge Hydraulic oil temperature gauge Fuel warmer Warnings Communication error Low battery • Communication error Low battery • Communication error	All-weather steel cab with 360° visibility	•	
Sliding side window (LH) Lockable door Hot and cool box Storage compartment and ashtray Transparent cabin roof cover Sun visor Door and cab locks, one key Mechanical suspension seat with heater Pilot-operated adjustable joystick Console box height adjust system Cabin lights Cabin front window rain guard Cabin roof-steel cover Automatic climate control Air conditioner and heater Defroster Starting aid (air grid heater) for cold weather Centralized monitoring 8" LCD display Engine speed or trip meter / accel. Engine coolant temperature gauge Max. power Low speed / high speed Auto idle Overload Check engine Air cleaner clogging Indicators ECO gauges Fuel level gauge Hydraulic oil temperature gauge Fuel warmer Warnings Communication error Low battery • Low battery • Communication error Low battery • Low battery		•	
Lockable door Hot and cool box Storage compartment and ashtray Transparent cabin roof cover Sun visor Door and cab locks, one key Mechanical suspension seat with heater Pilot-operated adjustable joystick Console box height adjust system Cabin lights Cabin front window rain guard Cabin roof-steel cover Automatic climate control Air conditioner and heater Defroster Starting aid (air grid heater) for cold weather Centralized monitoring 8" LCD display Engine speed or trip meter / accel. Engine coolant temperature gauge Max. power Low speed / high speed Auto idle Overload Check engine Air cleaner clogging Indicators ECO gauges Fuel level gauge Hydraulic oil temperature gauge Fuel warmer Warnings Communication error Low battery	Sliding fold-in front window	•	
Hot and cool box Storage compartment and ashtray Transparent cabin roof cover Sun visor Door and cab locks, one key Mechanical suspension seat with heater Pilot-operated adjustable joystick Console box height adjust system Cabin lights Cabin front window rain guard Cabin roof-steel cover Automatic climate control Air conditioner and heater Defroster Starting aid (air grid heater) for cold weather Centralized monitoring 8" LCD display Engine speed or trip meter / accel. Engine coolant temperature gauge Max. power Low speed / high speed Auto idle Overload Check engine Air cleaner clogging Indicators ECO gauges Fuel level gauge Hydraulic oil temperature gauge Eud warmer Warnings Communication error Low battery	Sliding side window (LH)	•	
Storage compartment and ashtray Transparent cabin roof cover Sun visor Door and cab locks, one key Mechanical suspension seat with heater Pilot-operated adjustable joystick Console box height adjust system Cabin lights Cabin front window rain guard Cabin roof-steel cover Automatic climate control Air conditioner and heater Defroster Starting aid (air grid heater) for cold weather Centralized monitoring 8" LCD display Engine speed or trip meter / accel. Engine coolant temperature gauge Max. power Low speed / high speed Auto idle Overload Check engine Air cleaner clogging Indicators ECO gauges Fuel level gauge Hydraulic oil temperature gauge Fuel warmer Warnings Communication error Low battery • Communication error Low battery	Lockable door	•	
Transparent cabin roof cover Sun visor Door and cab locks, one key Mechanical suspension seat with heater Pilot-operated adjustable joystick Console box height adjust system Cabin lights Cabin front window rain guard Cabin roof-steel cover Automatic climate control Air conditioner and heater Defroster Starting aid (air grid heater) for cold weather Centralized monitoring 8" LCD display Engine speed or trip meter / accel. Engine coolant temperature gauge Max. power Low speed / high speed Auto idle Overload Check engine Air cleaner clogging Indicators ECO gauges Fuel level gauge Hydraulic oil temperature gauge Warnings Communication error Low battery • Communication error Low battery	Hot and cool box	•	
Sun visor Door and cab locks, one key Mechanical suspension seat with heater Pilot-operated adjustable joystick Console box height adjust system Cabin lights Cabin front window rain guard Cabin roof-steel cover Automatic climate control Air conditioner and heater Defroster Starting aid (air grid heater) for cold weather Centralized monitoring 8" LCD display Engine speed or trip meter / accel. Engine coolant temperature gauge Max. power Low speed / high speed Auto idle Overload Check engine Air cleaner clogging Indicators ECO gauges Fuel level gauge Hydraulic oil temperature gauge Fuel warmer Warnings Communication error Low battery • Communication error Low battery • Communication error Low battery	Storage compartment and ashtray	•	
Door and cab locks, one key Mechanical suspension seat with heater Pilot-operated adjustable joystick Console box height adjust system Cabin lights Cabin front window rain guard Cabin roof-steel cover Automatic climate control Air conditioner and heater Defroster Starting aid (air grid heater) for cold weather Centralized monitoring 8" LCD display Engine speed or trip meter / accel. Engine coolant temperature gauge Max. power Low speed / high speed Auto idle Overload Check engine Air cleaner clogging Indicators ECO gauges Fuel level gauge Hydraulic oil temperature gauge Warnings Communication error Low battery • Communication error Low battery • Communication error Low battery	Transparent cabin roof cover	•	
Mechanical suspension seat with heater Pilot-operated adjustable joystick Console box height adjust system Cabin lights Cabin front window rain guard Cabin roof-steel cover Automatic climate control Air conditioner and heater Defroster Starting aid (air grid heater) for cold weather Centralized monitoring 8" LCD display Engine speed or trip meter / accel. Engine coolant temperature gauge Max. power Low speed / high speed Auto idle Overload Check engine Air cleaner clogging Indicators ECO gauges Fuel level gauge Hydraulic oil temperature gauge Fuel warmer Warnings Communication error Low battery • Communication error Low battery	Sun visor	•	
Pilot-operated adjustable joystick Console box height adjust system Cabin lights Cabin front window rain guard Acabin roof-steel cover Automatic climate control Air conditioner and heater Defroster Starting aid (air grid heater) for cold weather Centralized monitoring 8" LCD display Engine speed or trip meter / accel. Engine coolant temperature gauge Max. power Low speed / high speed Auto idle Overload Check engine Air cleaner clogging Indicators ECO gauges Fuel level gauge Hydraulic oil temperature gauge Warnings Communication error Low battery • Communication error Low battery	Door and cab locks, one key	•	
Console box height adjust system Cabin lights Cabin rort window rain guard Cabin roof-steel cover Automatic climate control Air conditioner and heater Defroster Starting aid (air grid heater) for cold weather Centralized monitoring 8" LCD display Engine speed or trip meter / accel. Engine coolant temperature gauge Max. power Low speed / high speed Auto idle Overload Check engine Air cleaner clogging Indicators ECO gauges Fuel level gauge Hydraulic oil temperature gauge Engine speed Warnings Communication error Low battery	Mechanical suspension seat with heater	•	
Cabin lights Cabin front window rain guard Cabin roof-steel cover Automatic climate control Air conditioner and heater Defroster Starting aid (air grid heater) for cold weather Centralized monitoring 8" LCD display Engine speed or trip meter / accel. Engine coolant temperature gauge Max. power Low speed / high speed Auto idle Overload Check engine Air cleaner clogging Indicators ECO gauges Fuel level gauge Hydraulic oil temperature gauge Fuel warmer Warnings Communication error Low battery • Communication error Low battery	Pilot-operated adjustable joystick	•	
Cabin front window rain guard Cabin roof-steel cover Automatic climate control Air conditioner and heater Defroster Starting aid (air grid heater) for cold weather Centralized monitoring 8" LCD display Engine speed or trip meter / accel. Engine coolant temperature gauge Max. power Low speed / high speed Auto idle Overload Check engine Air cleaner clogging Indicators ECO gauges Fuel level gauge Hydraulic oil temperature gauge Hydraulic oil temperature gauge Warnings Communication error Low battery	Console box height adjust system	•	
Cabin roof–steel cover Automatic climate control Air conditioner and heater Defroster Starting aid (air grid heater) for cold weather Centralized monitoring 8" LCD display Engine speed or trip meter / accel. Engine coolant temperature gauge Max. power Low speed / high speed Auto idle Overload Check engine Air cleaner clogging Indicators ECO gauges Fuel level gauge Hydraulic oil temperature gauge Warnings Communication error Low battery • Communication error Low battery	Cabin lights	•	
Automatic climate control Air conditioner and heater Defroster Starting aid (air grid heater) for cold weather Centralized monitoring 8" LCD display Engine speed or trip meter / accel. Engine coolant temperature gauge Max. power Low speed / high speed Auto idle Overload Check engine Air cleaner clogging Indicators ECO gauges Fuel level gauge Hydraulic oil temperature gauge Fuel warmer Warnings Communication error Low battery • Communication error Low battery	Cabin front window rain guard		•
Air conditioner and heater Defroster Starting aid (air grid heater) for cold weather Centralized monitoring 8" LCD display Engine speed or trip meter / accel. Engine coolant temperature gauge Max. power Low speed / high speed Auto idle Overload Check engine Air cleaner clogging Indicators ECO gauges Fuel level gauge Hydraulic oil temperature gauge Warnings Communication error Low battery	Cabin roof–steel cover		•
Defroster Starting aid (air grid heater) for cold weather Centralized monitoring 8" LCD display Engine speed or trip meter / accel. Engine coolant temperature gauge Max. power Low speed / high speed Auto idle Overload Check engine Air cleaner clogging Indicators ECO gauges Fuel level gauge Hydraulic oil temperature gauge Warnings Communication error Low battery	Automatic climate control		
Starting aid (air grid heater) for cold weather Centralized monitoring 8" LCD display Engine speed or trip meter / accel. Engine coolant temperature gauge Max. power Low speed / high speed Auto idle Overload Check engine Air cleaner clogging Indicators ECO gauges Fuel level gauge Hydraulic oil temperature gauge Warnings Communication error Low battery	Air conditioner and heater	•	
Centralized monitoring 8" LCD display Engine speed or trip meter / accel. Engine coolant temperature gauge Max. power Low speed / high speed Auto idle Overload Check engine Air cleaner clogging Indicators ECO gauges Fuel level gauge Hydraulic oil temperature gauge Warnings Communication error Low battery •	Defroster	•	
8" LCD display Engine speed or trip meter / accel. Engine coolant temperature gauge Max. power Low speed / high speed Auto idle Overload Check engine Air cleaner clogging Indicators ECO gauges Fuel level gauge Hydraulic oil temperature gauge Fuel warmer Warnings Communication error Low battery	Starting aid (air grid heater) for cold weather	•	
Engine speed or trip meter / accel. Engine coolant temperature gauge Max. power Low speed / high speed Auto idle Overload Check engine Air cleaner clogging Indicators ECO gauges Fuel level gauge Hydraulic oil temperature gauge Fuel warmer Warnings Communication error Low battery	Centralized monitoring		
Engine coolant temperature gauge Max. power Low speed / high speed Auto idle Overload Check engine Air cleaner clogging Indicators ECO gauges Fuel level gauge Hydraulic oil temperature gauge Fuel warmer Warnings Communication error Low battery • • • Communication error Low battery	8" LCD display	•	
Max. power Low speed / high speed Auto idle Overload Check engine Air cleaner clogging Indicators ECO gauges Fuel level gauge Hydraulic oil temperature gauge Fuel warmer Warnings Communication error Low battery	Engine speed or trip meter / accel.	•	
Low speed / high speed Auto idle Overload Check engine Air cleaner clogging Indicators ECO gauges Fuel level gauge Hydraulic oil temperature gauge Fuel warmer Warnings Communication error Low battery	Engine coolant temperature gauge	•	
Auto idle Overload Check engine Air cleaner clogging Indicators ECO gauges Fuel level gauge Hydraulic oil temperature gauge Fuel warmer Warnings Communication error Low battery • • • • • • • • • • • • •	Max. power	•	
Overload Check engine Air cleaner clogging Indicators ECO gauges Fuel level gauge Hydraulic oil temperature gauge Fuel warmer Warnings Communication error Low battery	Low speed / high speed	•	
Check engine Air cleaner clogging Indicators ECO gauges Fuel level gauge Hydraulic oil temperature gauge Fuel warmer Warnings Communication error Low battery	Auto idle	•	
Air cleaner clogging Indicators ECO gauges Fuel level gauge Hydraulic oil temperature gauge Fuel warmer Warnings Communication error Low battery • • • • • • • • • • • • •	Overload		•
Indicators ECO gauges Fuel level gauge Hydraulic oil temperature gauge Fuel warmer Warnings Communication error Low battery • • • • • • • • • • • • •	Check engine	•	
ECO gauges Fuel level gauge Hydraulic oil temperature gauge Fuel warmer Warnings Communication error Low battery • • • • • • • • • • • • •	Air cleaner clogging	•	
ECO gauges Fuel level gauge Hydraulic oil temperature gauge Fuel warmer Warnings Communication error Low battery • • • • • • • • • • • • •	Indicators	•	
Hydraulic oil temperature gauge Fuel warmer Warnings Communication error Low battery • • • • • • • • • • • • •	ECO gauges	•	
Fuel warmer Warnings Communication error Low battery •	Fuel level gauge	•	
Fuel warmer Warnings Communication error Low battery •	Hydraulic oil temperature gauge	•	
Communication error • Low battery •		•	
Communication error • Low battery •	Warnings	•	
		•	
	Low battery	•	
		•	

CAB & INTERIOR	STD	OPT
Seat		
Adjustable air suspension seat with heater	•	
Cabin FOPS/FOG		
FOG ISO 10262 Level 2 Front and top guard		•
(FOPS ISO 3449 Level 2) Top guard		•
Cabin ROPS		
ROPS ISO 12117-2	•	
SAFETY	STD	ОРТ
Battery master switch	•	
Rearview camera	•	
AAVM (All-Around View Monitoring)		•
Six front working lights (4 boom mounted, 2 front frame mounted)	•	
Dual boom working lights	•	
Travel alarm	•	
Rear work lamp		•
Beacon lamp		•
Automatic swing brake	•	
Boom holding system	•	
Arm holding system	•	
Safety lock valve for boom cylinder with overload warning device		•
Safety lock valve for arm cylinder		•
Swing Lock System		•
Three outside rearview mirrors	•	
OTHER	STD	OPT
Booms		
6.15 m, 20' 2"		•
6.45 m, 21' 2"	•	
Arms		
2.2 m, 7' 3"		•
2.5 m, 8' 2"		•
3.2 m, 10' 6"	•	
4.05 m, 13' 3"		•
Removable clean-out dust net for cooler	•	
Removable reservoir tank	•	
Fuel pre-filter	•	
Fuel warmer		•
Self-diagnostics system	•	
Hi-mate Remote Management System Mobile	•	
Safellife		•
Batteries (2 x 12V x 160 Ah)	•	
Fuel-filler pump (50 l/min / 13 gpm)		•
Single-acting piping kit (breaker, etc.)		•
Double-acting piping kit (clamshell, etc.)	•	
Rotating piping kit		•
Quick coupler piping		•
Quick coupler		•
Boom float control		•
One-pedal straight travel system		•
Pilot accumulator	•	
Pattern-change valve (SAE and ISO) Tool kit	•	
UNDERCARRIAGE	STD	OPT
Lower frame under cover (additional)		•
Lower frame under cover (normal)	•	
Track shoes		
Triple grouser shoes (700 mm, 28")		•
Triple grouser shoes (800 mm, 32")	•	
Triple grouser shoes (900 mm, 36")		•
Track rail guard	•	
Full track rail guard		•

NOTE: Standard and optional equipment may vary. Materials and specifications are subject to change without advance notice. Contact your Hyundai dealer for more information.

A HYUNDAI CONSTRUCTION EQUIPMENT

www.hceamericas.com 6100 Atlantic Blvd., Norcross, GA 30071 TEL (678) 823 7777 FAX (678) 823 7778

PLEASE CONTA	/C
--------------	----

1016-EX-SP 2/2018v7