

HL940

Part No	Part Name	Group Name	Start S/No		
			Start S/No	-	End S/No
11KA-71040	Filter-Fuel	Fuel Tank			
11LK-00070	Gear-Selector	Cab Room Electric 3			
11LL-45181	Element-A/C Outer	Air Intake System	#0005	-	
11LL-45190	Element-A/C Inner	Air Intake System			
11LM-00121	Dipstick Assy	Transmission Mounting			
11WB-90100	Belt-Aircon	Aircon & Heater Mounting			
14E7-01070	Gauge-Level	Cooling Group			
21LL-08210	Sensor-Speed	Rear Electric 1			
21LM-37020	Arm&Blade Assy-Wiper			-	#0562
21LM-37021	Arm&Blade Assy-Wiper	Cab Electric 2	#0563	-	
21LM-37060	Blade Assy-Wiper	Cab Electric 2			
21WD-50400	Blade Assy-Wiper Rr	Cab Electric 2			
24L3-41210	Arm Assy-Wiper	Cab Electric 2	#0563	-	
2872277	Sensor-Position	Engine Control Module (Ecm)			
3035960	Ring-Retainer	Fan Drive			
3058653	O-Ring	Exhaust Recirculation Water Plumbing			
3093730	Screw-Hex	Camshaft			
31E3-4529	Strainer-Suction	Hydraulic Tank Assy			
31EE-02100	Breather Assy-Air	Hydraulic Tank Assy			
31EE-02110	Element-Breather	Hydraulic Tank Assy			
31LM-10310	Filter-Line	Safety Valve			
31LM-90030	Accumulator	Accumulator			
31LN-30010	Valve Assy-Steering	Steering Unit			
33Q6-02700	Gauge-Level	Hydraulic Tank Assy	#0011	-	
3678603	O-Ring	Turbocharger 1			
3684284	Washer	Turbocharger 1			
3802924	Valve Kit-Intake	Cylinder Head			
3864517	Valve-Drain	Remote Oil Drain			
3900630	Screw-Hex Flg	Crankcase Breather			
3901445	Screw-Hex Flg	Rear Gear Housing			
3902468	Cap-Filler	Oil Filler Arrangement			
3903464	Bolt-Hex	Flywheel Housing			
3904483	Pin-Dowel	Camshaft			

3906698	Seal	Water Pump			
3910739	Bearing-Ball	Fan Drive			
3914177	Bolt-Hex	Flywheel Housing			
3918109	Screw-Hex Flg	Air Intake Manifold			
3922794	O-Ring	Turbocharger 1			
3928624	O-Ring	Turbocharger Plumbing			
3937736	Filter-Oil	Full Flow Oil Filter			
3939719	Guide-Valve/Inlet	Cylinder Head			
3943198	Retainer	Cylinder Head			
3944593	Bolt	Exhaust Recirculation			
3945252	Spacer-Mount	Exhaust Recirculation			
3954829	Seal	Thermostat			
3963983	Washer-Seal	Drain Location			
3963988	Washer-Seal	Fuel Drain Plumbing			
3963990	Washer-Seal	Fuel Drain Plumbing			
3973511	Cap-Filler	Valve Cover Arrangement			
3977393	O-Ring	Injector			
4010519	O-Ring	Exhaust Recirculation			
4076930	Sensor-Pressure	Engine Control Module (Ecm)			
41LN-10080	Collar	Center Pivot Pin (Lower)			
41LN-10090	Collar	Center Pivot Pin (Lower)			
4309416	Valve Kit-Egr	Exhaust Recirculation			
4326470	Sensor-Nitrogen	Aftertreatment Device (Not Used)			
4326862	Sensor-Nitrogen	Aftertreatment Device (#0001-)			
4894641	Bolt-Hex	Flywheel & Mounting			
4921322	Sensor-Temp	Engine Control Module (Ecm)			
4921574	O-Ring	Engine Control Module (Ecm)			
4928594	Sensor-Pressure	Exhaust Recirculation			
4934074	Insert-Valve	Cylinder Head			
4934278	Washer	Engine Coolant Vent			
4936636	Element-Breather	Crankcase Breather			
4954905	Sensor-Temp	Engine Control Module (Ecm)			
5256546	Tensioner Assy-Belt	Belt Tensioner			
5264181	Retainer	Injector Plumbing			
5274458	Screen	Fuel Filter Location			
5291751	Seal	Injector			

5292708	Thermostat	Thermostat			
5303743	Filter-Fuel	Fuel Filter Location			
5305254	Injector-Reactor	Aftertreatment Device (Not Used)			
5306012	Connector	Turbocharger Plumbing			
5306267	Connector	Turbocharger Plumbing			
61L3-0169GG	Tooth-Center	Bucket (2.0m3, Tooth)			
61Q6-06500	O-Ring	Bell Crank & Link			
64L3-01300	Pin-Tooth	Bucket (2.2m3, 2-Pcs Tooth)			
71WC-41140	Latch	Engine Hood 1			
71WC-41150	Cable-Control	Engine Hood 1			
71WD-01381	Latch-Door	Cab Sub Assy (4/4, Lh Door Assy)			
71WD-02771	Catch Assy	Cab Sub Assy (1/4)			
71WD-03720	Latch-Door	Cab Sub Assy (4/4, Lh Door Assy)			
71WD-04040	Spring-Retainer	Cab Sub Assy (3/4)		-	#0004
71WD-32220	Filter-Aircon	Aircon & Heater Unit	#0002	-	
71WD-41320	Latch-Cam	Ladder & Handrail 3		-	#0279
71WD-78010	Latch-Cam	Ladder & Handrail 3	#0280	-	
71WD-78020	Latch-Cam	Ladder & Handrail 1	#0280	-	
76LL-60280	Latch Assy	Ladder & Handrail 1		-	#0279
81WB-30021	Shaft-Drive Ct		#0671	-	#1183
81WB-30400	Bearing Assy-Center	Drive Lines			
91E1-26300	Step-Tread	Decals (English)		-	#1062
91N6-03133	Hose-H/Pressure	Decals (English)	#0186	-	
E131-0473	Gauge-Level	Hydraulic Tank Assy		-	#0010
E131-0594	Spring	Hydraulic Tank Assy			
G58075F0	O-Ring	Aircon & Heater Mounting			
S611-009001	O-Ring	Pilot Hydraulic Piping 2			
S611-012001	O-Ring	Radiator Sub Assy			
S611-016001	O-Ring	Brake Hydraulic Piping 1			
S611-019001	O-Ring	Radiator Sub Assy			
S611-023001	O-Ring	Emergency Steering Hyd Piping			
S621-012001	O-Ring	Cooling Group			
S621-014001	O-Ring	Radiator Sub Assy			
S621-018001	O-Ring	Cooling Group			
S621-021001	O-Ring	Cooling Group			
S631-011004	O-Ring	Main Hydraulic Piping			

S631-014001	O-Ring	Quick Coupler Piping			
S631-014004	O-Ring	Main Hydraulic Piping			
S631-018001	O-Ring	Fuel Tank			
S631-018004	O-Ring	Engine Mounting			
S631-024004	O-Ring	Cooling Group			
S631-029004	O-Ring	Radiator Sub Assy			
S632-055004	O-Ring	Bucket Cylinder			
S632-105004	O-Ring	Boom Cylinder			
S632-125004	O-Ring	Bucket Cylinder			
S632-140004	O-Ring	Hydraulic Tank Assy			
S632-165001	O-Ring	Fuel Tank			
S632-220001	O-Ring	Fuel Tank			
X500-110001	Connector-Orfs	Pilot Hydraulic Piping 2			
XKBL-00084	Coil	Cut Off Valve			
XKBL-00090	Plug-Wrench	Cut Off Valve			
XKBL-00096	Plug-Wrench	Directional Valve		-	#1244
XKBU-00045	O-Ring	Aircon & Heater Mounting			
XKBU-00144	Filter-Aircon	Aircon & Heater Unit		-	#0001
XKCC-00896	O-Ring	Boom Cylinder(Shpac,#0470-)	#0470	-	
XKCF-00013	O-Ring	Fuel Tank			
XKCP-00524	Plug			-	#0670
XKCT-00002	Breather-Air	Hydraulic Tank Assy			
XKDR-00054	O-Ring	Brake Hydraulic Piping 2		-	#1062
Y161-014001	O-Ring	Fuel Tank			
Y161-016001	O-Ring	Differential Lock Group	#0257	-	
Y161-018001	O-Ring	Brake Hydraulic Piping 1			
Y171-015004	O-Ring	Cooling Group		-	#0546
Y171-019004	O-Ring	Cooling Group		-	#0546
Y171-024004	O-Ring	Main Hydraulic Piping		-	#0115
Y171-027004	O-Ring	Brake Hydraulic Piping 2		-	#0535
Y172-003004	O-Ring	Pilot Hydraulic Piping 2		-	#0535
Y172-006004	O-Ring	Main Hydraulic Piping		-	#0535
YUBP-03667	Sensor-Temp	Air Intake System	#0001	-	
ZFAB-00094	Button Kit	Remote Control Lever (2-Spool)			
ZFAB-00120	Plunger Kit	Remote Control Lever (3-Spool)			
ZFAB-00126	Handle	Remote Control Lever (2-Spool)			

ZGAQ-00085	O-Ring	Front Axle Bracket		
ZGAQ-00161	Nut-Wheel	Front Axle Parts		
ZGAQ-00231	O-Ring	Gearshift System (2/3)		
ZGAQ-00251	Washer	Parking Brake		
ZGAQ-00253	O-Ring	Gearbox Housing Group (1/2)		
ZGAQ-00258	Breather	Gearbox Housing Group (1/2)		
ZGAQ-00597	O-Ring	Front Axle Output		
ZGAQ-00608	Screw-Torx	Gearshift System (1/3)		
ZGAQ-00628	Screw-Trox	Gearshift System (2/3)		
ZGAQ-00629	Regulator-Pressure	Gearshift System (2/3)		
ZGAQ-00630	O-Ring	Gearshift System (2/3)		
ZGAQ-00633	Harness-Wire	Gearshift System (2/3)		
ZGAQ-00639	Screen	Gearshift System (3/3)		
ZGAQ-00641	Screw-Torx	Gearshift System (3/3)		
ZGAQ-00651	Transmitter-Indicator	Indicator Transmitter Group		
ZGAQ-00653	Transmitter-Indicator	Indicator Transmitter Group		
ZGAQ-00654	O-Ring	Indicator Transmitter Group		
ZGAQ-00673	Gasket	Filler Neck		
ZGAQ-00697	Switch-Tappet	Gearshift System (1/3)		
ZGAQ-00758	Screw	Engine Connection Group		
ZGAQ-00761	Screw-Hex	Engine Connection Group		
ZGAQ-00762	Washer	Engine Connection Group		
ZGAQ-00778	Seal-Oil	Pressure Oil Pump		
ZGAQ-00790	Gasket	Gearbox Housing Group (1/2)		
ZGAQ-00792	Screw-Cap	Gearbox Housing Group (1/2)		
ZGAQ-00793	Screw-Cap	Gearbox Housing Group (1/2)		
ZGAQ-00814	O-Ring	Coupling Group (K1)		
ZGAQ-00825	Cage-Needle	Coupling Group (K1)		
ZGAQ-00826	Washer	Coupling Group (K1)		
ZGAQ-00831	Ring-Piston	Coupling Group (K1)		
ZGAQ-00850	O-Ring	Coupling Group (K1)		
ZGAQ-00903	Spring-Compression	Gearshift System (1/3)		
ZGAQ-00912	Spring-Compression	Pressure Regulator		
ZGAQ-00923	O-Ring	Temperature Sensor		
ZGAQ-00925	Head-Filter	Filter		
ZGAQ-00964	O-Ring	Front Axle Parts		

ZGAQ-01397	Ring Set-Piston	Input Group			
ZGAQ-01440	Seal-Oil	Output Group			
ZGAQ-01441	O-Ring	Output Group			
ZGAQ-01442	Washer	Output Group			
ZGAQ-01443	Screw	Output Group			
ZGAQ-01445	Flange-Input	Output Group			
ZGAQ-01448	Ring-Piston	Power Take Off Group			
ZGAQ-01454	Piston	Gearshift System (1/3)			
ZGAQ-01460	Screw-Cap	Pressure Oil Pump			
ZGAQ-01461	O-Ring	Pressure Oil Pump			
ZGAQ-01466	O-Ring	Indicator Transmitter Group			
ZGAQ-01578	Gasket	Gearshift System (2/3)			
ZGAQ-01579	Gasket	Gearshift System (2/3)			
ZGAQ-01614	Plug-Screw	Front Axle Parts			
ZGAQ-01615	Seal	Front Axle Parts			
ZGAQ-01924	Sensor-Temp	Temperature Sensor			
ZGAQ-01940	O-Ring	Coupling Group (K2)			
ZGAQ-02192	O-Ring	Front Axle Drive Housing			
ZGAQ-02200	Valve-Vent	Front Axle Output			
ZGAQ-02391	O-Ring	Gearbox Housing Group (2/2)			
ZGAQ-02400	Filter-Transmission	Filter			
ZGAQ-02401	O-Ring	Filter			
ZGAQ-02444	Seal-Shaft	Front Axle Drive Housing			
ZGAQ-02446	Nut-Hex	Front Axle Drive Housing			
ZGAQ-02485	O-Ring	Front Axle Bracket			
ZGAQ-02492	Cover	Front Axle Output			
ZGAQ-02506	Ring-U	Front Axle Brake			
ZGAQ-02507	Ring-Support	Front Axle Brake			
ZGAQ-02508	Ring-U	Front Axle Brake			
ZGAQ-02509	Ring-Support	Front Axle Brake			
ZGAQ-02510	Ring-Guide	Front Axle Brake			
ZGAQ-02563	Screw-Lock	Front Axle Differential (Normal)			
ZGAQ-02576	O-Ring	Front Axle Bracket			
ZGAQ-02577	Screw-Hex	Rear Axle Bracket			
ZGAQ-02586	Gear-Planet	Front Axle Output			
ZGAQ-02591	Ring-U	Rear Axle Brake			

ZGAQ-02592	Ring-U	Rear Axle Brake			
ZGAQ-02594	Pin-Slot	Front Axle Brake			
ZGAQ-02599	Pipe-Brake	Front Axle Parts			
ZGAQ-02621	Screw-Hex	Parking Brake			
ZGAQ-02809	O-Ring	Pressure Oil Pump			
ZGAQ-02830	Pump Assy-Gear	Pressure Oil Pump			
ZGAQ-02855	Sheet-Screen	Parking Brake			
ZGAQ-03557	Brake-Parking	Parking Brake			
ZGAQ-03558	Seal Kit	Parking Brake			
ZGAQ-03563	Repair Kit	Parking Brake			
ZGAQ-03564	Lining Kit-Brake	Parking Brake			
ZGAQ-03565	Repair Kit	Parking Brake			
ZGAQ-03575	O-Ring	Power Take Off Group			
ZGAQ-03581	Plug-Screw	Front Axle Drive Housing			
ZGAQ-03746	Screw-Locking	Front Axle Output			
ZGAQ-03771	Screw-Hex	Front Axle Brake			
ZGAQ-03903	O-Ring	Rear Axle Brake			
ZGAQ-03906	Seal	Front Axle Output			
ZGAQ-03915	Washer	Front Axle Brake			
ZGAQ-03916	Spring-Cup	Front Axle Brake			
ZGAQ-03917	Cover	Front Axle Brake			
ZGAQ-03940	Plug-Screw	Front Axle Bracket			
ZGAQ-03946	Shim-End	Front Axle Brake			
ZGAQ-04085	Bearing-Taperroller	Input Group			
ZGAQ-04136	Bolt-Wheel	Front Axle Output			
ZGAQ-04388	Gear-Planet	Front Axle Output			
ZGAQ-04390	Bolt-Stop	Front Axle Output			
ZGAQ-04412	Sheet-Intermediate	Gearshift System (1/3)			
ZGAQ-04413	Plate-Seal	Gearshift System (3/3)			
ZGAQ-04589	Nut-Wheel	Rear Axle Parts			
ZGAQ-04805	Piston-Brake	Front Axle Brake			
ZGAQ-04807	Screw-Sleeve	Front Axle Parts			
ZGAQ-04874	Piston	Rear Axle Brake			
ZGAR-00620	Screw	Main Control Valve (2/2, 2-Spool)		-	#0564
ZGAR-00620	Screw			-	#0564
ZGAR-00629	Spring-Compression	Main Control Valve (2/2, 2-Spool)			

ZGAR-00630	Retainer-Spring	Main Control Valve (2/2, 2-Spool)		-	#0564
ZGAR-00676	Valve Assy-Relief/Press			-	#0564
ZGAR-00761	Screw-Cyl	Main Control Valve (2/2, 2-Spool)	#0565	-	
ZGAW-00008	Coil	Safety Valve			
ZGAW-00056	Plug-Cavity	Ride Control Valve			
ZGBP-00320	Valve-Control	Fan & Brake Pump			