

HL955

Part No	Part Name	Group Name	Start S/No		
			Start S/No	-	End S/No
11K9-31100	Clamp	Exhaust System			
11KA-71040	Filter-Fuel	Fuel Tank			
11LK-00070	Gear-Selector	Cab Room Electric 3 (Eh, Hyd, #0001-)	#0001	-	
11LL-45181	Element-A/C Outer	Air Intake System	#0047	-	
11LL-45190	Element-A/C Inner	Air Intake System			
11LM-00121	Dipstick Assy	Transmission Mounting			
11U6-00200	Sensor-Temp	Front Electric 1	#0097	-	
11WB-90100	Belt-Aircon	Aircon & Heater Mounting			
14E7-01070	Gauge-Level	Cooling Group			
21LL-08210	Sensor-Speed	Rear Electric 1			
21LM-37020	Arm&Blade Assy-Wiper			-	#0426
21LM-37021	Arm&Blade Assy-Wiper	Cab Electric 2	#0427	-	
21LM-37060	Blade Assy-Wiper	Cab Electric 2			
21WD-37500	Control Unit-Start Key	Cab Room Electric 3 (Eh, Hyd, #0001-)	#0432	-	
21WD-50400	Blade Assy-Wiper Rr	Cab Electric 2			
24L3-41210	Arm Assy-Wiper	Cab Electric 2	#0427	-	
2872277	Sensor-Position	Engine Control Module (Ecm)			
2888173	Injector-Dozer	After Treatment Device			
3035960	Ring-Retainer	Fan Drive			
3058653	O-Ring	Exhaust Recirculation Water Plumbing			
3093730	Screw-Hex	Camshaft			
31EE-02100	Breather Assy-Air	Hydraulic Tank Assy			
31EE-02110	Element-Breather	Hydraulic Tank Assy			
31LM-10310	Filter-Line	Safety Valve			
31LM-90040	Accumulator	Accumulator			
31LN-30010	Valve Assy-Steering	Steering Unit (Direct Steering)	#0332	-	
31M6-52140	Gauge-Level	Hydraulic Tank Assy			
31WC-30010	Valve Assy-Steering	Steering Unit (Ehps Steering)			
31WD-60210	Element-Suction	Hydraulic Tank Assy			
3678603	O-Ring	Turbocharger			
3684284	Washer	Turbocharger			
3802924	Valve Kit-Intake	Cylinder Head			
3864517	Valve-Drain	Remote Oil Drain			
3900630	Screw-Hex Flg	Crankcase Breather			
3901445	Screw-Hex Flg	Rear Gear Housing			

3902468	Cap-Filler	Oil Filler Arrangement		
3903464	Bolt-Hex	Flywheel Housing Mounting		
3904483	Pin-Dowel	Camshaft		
3906698	Seal	Water Pump		
3910739	Bearing-Ball	Fan Drive		
3918109	Screw-Hex Flg	Air Intake Manifold		
3922794	O-Ring	Turbocharger		
3928624	O-Ring	Turbocharger Plumbing		
3937736	Filter-Oil	Full Flow Oil Filter		
3939719	Guide-Valve/Inlet	Cylinder Head		
3943198	Retainer	Cylinder Head		
3944593	Bolt	Exhaust Recirculation		
3945252	Spacer-Mount	Exhaust Recirculation		
3954829	Seal	Thermostat		
3963983	Washer-Seal	Drain Location		
3963988	Washer-Seal	Fuel Drain Plumbing		
3963990	Washer-Seal	Fuel Drain Plumbing		
3973511	Cap-Filler	Valve Cover Arrangement		
3977393	O-Ring	Injector		
4010519	O-Ring	Exhaust Recirculation		
4076930	Sensor-Pressure	Engine Control Module (Ecm)		
41LM-10080	Collar	Center Pivot Pin (Lower)	-	#0918
41LM-10080	Collar		-	#0918
41LM-10090	Collar	Center Pivot Pin (Lower)	-	#0918
41LM-10090	Collar		-	#0918
4309416	Valve Kit-Egr	Exhaust Recirculation		
4326862	Sensor-Nitrogen	After Treatment Device		
4894641	Bolt-Hex	Flywheel & Mounting		
4921322	Sensor-Temp	Engine Control Module (Ecm)		
4921574	O-Ring	Engine Control Module (Ecm)		
4928395	Sensor-Temp	Air Cleaner Sensor		
4928594	Sensor-Pressure	Exhaust Recirculation		
4934074	Insert-Valve	Cylinder Head		
4934278	Washer	Engine Coolant Vent		
4936636	Element-Breather	Crankcase Breather		
4954905	Sensor-Temp	Engine Control Module (Ecm)		
5256546	Tensioner Assy-Belt	Belt Tensioner		
5264181	Retainer	Injector Plumbing		

5274458	Screen	Fuel Filter Location			
5291751	Seal	Injector			
5292708	Thermostat	Thermostat			
5303743	Filter-Fuel	Fuel Filter Location			
5306012	Connector	Turbocharger Plumbing			
5306267	Connector	Turbocharger Plumbing			
61L8-30381	Boss	Bell Crank & Link			
61Q6-06500	O-Ring	Bell Crank & Link	#0211	-	
64L3-01300	Pin-Tooth	Bucket (2.7m3, 2-Piece Tooth)			
71WC-41140	Latch	Engine Hood 1			
71WC-41150	Cable-Control	Engine Hood 1			
71WD-01381	Latch-Door	Cab Sub Assy (4/4, Lh Door Assy)			
71WD-02771	Catch Assy	Cab Sub Assy (1/4)			
71WD-03720	Latch-Door	Cab Sub Assy (4/4, Lh Door Assy)			
71WD-04040	Spring-Retainer	Cab Sub Assy (3/4)		-	#0081
71WD-32220	Filter-Aircon	Aircon & Heater Unit	#0002	-	
71WD-41320	Latch-Cam	Ladder & Handrail 3		-	#0205
71WD-78010	Latch-Cam	Ladder & Handrail 3	#0206	-	
71WD-78020	Latch-Cam	Ladder & Handrail 1	#0206	-	
72LM-43211	Boss	Radiator Sub Assy			
72LM-60180	Latch Assy	Ladder & Handrail 1			
76LL-60280	Latch Assy	Ladder & Handrail 1		-	#0205
91E1-26300	Step-Tread	Cab Sub Assy (1/4)			
91N6-03133	Hose-H/Pressure	Decals (English)	#0155	-	
91N6-05120	Decal-Tie	Decals (English)		-	#0386
91Q4-07920	Decal-Caution	Decals (English)			
91Q6-03230	Decal-Fuel	Decals (English)			
E131-0594	Spring	Hydraulic Tank Assy			
G58075F0	O-Ring	Aircon & Heater Mounting			
S611-009001	O-Ring	Pilot Hydraulic Piping 2 (Eh)			
S611-012001	O-Ring	Pilot Hydraulic Piping 2 (Eh)			
S611-016001	O-Ring	Radiator Sub Assy			
S611-019001	O-Ring	Main Hydraulic Piping 2			
S611-023001	O-Ring	Radiator Sub Assy			
S621-012001	O-Ring	Cooling Group			
S621-014001	O-Ring	Cooling Group			
S621-018001	O-Ring	Cooling Group			
S621-021001	O-Ring	Pilot Hydraulic Piping 3 (Eh, 3-Spool)			

S621-025001	O-Ring	Main Hydraulic Piping 1			
S631-011001	O-Ring	Fuel Tank			
S631-011004	O-Ring	Main Hydraulic Piping 1			
S631-014001	O-Ring	Quick Coupler Piping			
S631-014004	O-Ring	Pilot Hydraulic Piping 1 (Eh)			
S631-016004	O-Ring	Axle Oil Cooling Group 1 (Option)	#0108	-	
S631-018004	O-Ring	Engine Mounting			
S631-024001	O-Ring	Radiator Sub Assy			
S631-024004	O-Ring	Cooling Group	#0001	-	
S631-029004	O-Ring	Main Hydraulic Piping 2			
S631-030001	O-Ring	Emergency Steering Hyd Piping	#0332	-	
S631-038004	O-Ring	Main Hydraulic Piping 1			
S632-055004	O-Ring	Boom Cylinder			
S632-125004	O-Ring	Boom Cylinder			
S632-140001	O-Ring	Hydraulic Tank Assy			
S632-140004	O-Ring	Hydraulic Tank Assy			
S632-165001	O-Ring	Fuel Tank			
X500-110001	Connector-Orfs	Pilot Hydraulic Piping 2 (Eh)		-	#0572
XCAV-00026	O-Ring	Main Hydraulic Piping 1		-	#0420
XCAV-00127	O-Ring	Boom Cylinder			
XIAA-00020	O-Ring	Wheel Rim & Tire			
XKBL-00084	Coil	Cut Off Valve			
XKBL-00090	Plug-Wrench	Cut Off Valve			
XKBL-00096	Plug-Wrench	Directional Valve (-#0012)		-	#0012
XKBL-00096	Plug-Wrench		#0013	-	#0932
XKBU-00045	O-Ring	Aircon & Heater Mounting			
XKBU-00144	Filter-Aircon	Aircon & Heater Unit		-	#0001
XKCC-00139	O-Ring	Steering Cylinder			
XKCF-00013	O-Ring	Fuel Tank			
XKCF-00402	O-Ring	Fuel Tank			
XKCF-00723	O-Ring	Transmission Cooling Piping (4-Speed)			
XKCP-00128	Cover-Bearing	Drive Lines			
XKCT-00002	Breather-Air	Hydraulic Tank Assy			
XKDE-00630	Screw-Hex Flg	Flywheel Housing			
XKDE-01374	Screw-Hex Flg	Flywheel Housing			
XKDR-00054	O-Ring	Main Hydraulic Piping 1			
Y161-016001	O-Ring	Differential Lock Group			
Y161-018001	O-Ring	Brake Hydraulic Piping 1			

Y161-022001	O-Ring	Axle Oil Cooling Group 1 (Option)	#0108	-	
Y171-015004	O-Ring	Cooling Group		-	#0422
Y171-019004	O-Ring	Cooling Group	#0001	-	#0422
Y171-024004	O-Ring	Pilot Hydraulic Piping 3 (Hyd, 3-Spool) (-#0835)	#0001	-	#0381
Y171-027004	O-Ring	Main Hydraulic Piping 1		-	#0420
Y172-003004	O-Ring	Main Hydraulic Piping 2		-	#0420
Y172-006004	O-Ring	Main Hydraulic Piping 2		-	#0420
YUBP-03667	Sensor-Temp	Air Intake System	#0001	-	
ZFAB-00094	Button Kit	Remote Control Lever (Hyd, 2-Spool)	#0022	-	
ZFAB-00120	Plunger Kit	Remote Control Lever (Hyd, 3-Spool)	#0022	-	
ZFAB-00126	Handle	Remote Control Lever (Hyd, 2-Spool)	#0022	-	
ZGAQ-00085	O-Ring	Front Axle Casing Group			
ZGAQ-00099	O-Ring	Control Unit (5-Speed)			
ZGAQ-00161	Nut-Wheel	Rear Loose Parts Group			
ZGAQ-00231	O-Ring	Gearshift System 2 (4-Speed)			
ZGAQ-00251	Washer	Parking Brake (4-Speed)			
ZGAQ-00252	Plug-Screw	Gearbox Housing 1 (4-Speed)			
ZGAQ-00253	O-Ring	Gearbox Housing 1 (4-Speed)			
ZGAQ-00258	Breather	Gearbox Housing 1 (4-Speed)			
ZGAQ-00597	O-Ring	Power Take Off (4-Speed)			
ZGAQ-00608	Screw-Torx	Gearshift System 1 (4-Speed)			
ZGAQ-00628	Screw-Trox	Gearshift System 2 (4-Speed)			
ZGAQ-00629	Regulator-Pressure	Gearshift System 2 (4-Speed)			
ZGAQ-00630	O-Ring	Gearshift System 2 (4-Speed)			
ZGAQ-00633	Harness-Wire	Gearshift System 2 (4-Speed)			
ZGAQ-00639	Screen	Gearshift System 3 (4-Speed)			
ZGAQ-00641	Screw-Torx	Gearshift System 3 (4-Speed)			
ZGAQ-00651	Transmitter-Indicator	Ind Transmitter (4-Speed)			
ZGAQ-00653	Transmitter-Indicator	Ind Transmitter (4-Speed)			
ZGAQ-00654	O-Ring	Ind Transmitter (4-Speed)			
ZGAQ-00673	Gasket	Filler Neck (4-Speed)			
ZGAQ-00697	Switch-Tappet	Gearshift System 1 (4-Speed)			
ZGAQ-00758	Screw	Engine Connection (4-Speed)			
ZGAQ-00761	Screw-Hex	Engine Connection (4-Speed)			
ZGAQ-00762	Washer	Engine Connection (4-Speed)			
ZGAQ-00769	Bearing-Roller	Input Group (4-Speed)			
ZGAQ-00770	Ring Set-Piston	Input Group (5-Speed)			
ZGAQ-00778	Seal-Oil	Pressure Oil Pump (4-Speed)			

ZGAQ-00783	Screw-Cap	Gearbox Housing 1 (4-Speed)		
ZGAQ-00790	Gasket	Gearbox Housing 1 (4-Speed)		
ZGAQ-00792	Screw-Cap	Gearbox Housing 1 (4-Speed)		
ZGAQ-00793	Screw-Cap	Gearbox Housing 1 (4-Speed)		
ZGAQ-00814	O-Ring	Clutch (K1, 4-Speed)		
ZGAQ-00815	O-Ring	Clutch (K1, 4-Speed)		
ZGAQ-00816	Spring-Cup	Clutch (K1, 4-Speed)		
ZGAQ-00825	Cage-Needle	Clutch (K1, 4-Speed)		
ZGAQ-00826	Washer	Clutch (K1, 4-Speed)		
ZGAQ-00831	Ring-Piston	Clutch (K1, 4-Speed)		
ZGAQ-00850	O-Ring	Clutch (K2, 4-Speed)		
ZGAQ-00890	Seal-Oil	Output Group (4-Speed)		
ZGAQ-00893	O-Ring	Output Group (4-Speed)		
ZGAQ-00903	Spring-Compression	Gearshift System 1 (4-Speed)		
ZGAQ-00912	Spring-Compression	Pressure Regulator (4-Speed)		
ZGAQ-00923	O-Ring	Temp Sensor (4-Speed)		
ZGAQ-00925	Head-Filter	Filter (4-Speed)		
ZGAQ-00964	O-Ring	Rear Axle Part Group		
ZGAQ-01212	O-Ring	Rear Axle Part Group		
ZGAQ-01397	Ring Set-Piston	Input Group (4-Speed)		
ZGAQ-01454	Piston	Gearshift System 1 (4-Speed)		
ZGAQ-01460	Screw-Cap	Pressure Oil Pump (4-Speed)		
ZGAQ-01461	O-Ring	Pressure Oil Pump (4-Speed)		
ZGAQ-01466	O-Ring	Ind Transmitter (4-Speed)		
ZGAQ-01516	Gasket	Gearshift System 1 (4-Speed)		
ZGAQ-01538	O-Ring	Front Output Group		
ZGAQ-01578	Gasket	Gearshift System 2 (4-Speed)		
ZGAQ-01579	Gasket	Gearshift System 2 (4-Speed)		
ZGAQ-01598	Seal-Oil	Front Axle Drive Housing		
ZGAQ-01600	Nut-Slot	Front Axle Drive Housing		
ZGAQ-01614	Plug-Screw	Front Axle Part Group		
ZGAQ-01615	Seal	Front Axle Part Group		
ZGAQ-01924	Sensor-Temp	Temp Sensor (4-Speed)		
ZGAQ-02192	O-Ring	Front Axle Drive Housing		
ZGAQ-02200	Valve-Vent	Front Output Group		
ZGAQ-02391	O-Ring	Gearbox Housing 2 (4-Speed)		
ZGAQ-02400	Filter-Transmission	Filter (4-Speed)		
ZGAQ-02401	O-Ring	Filter (4-Speed)		

ZGAQ-02444	Seal-Shaft	Rear Axle Drive Housing			
ZGAQ-02446	Nut-Hex	Rear Axle Drive Housing			
ZGAQ-02485	O-Ring	Front Axle Casing Group			
ZGAQ-02492	Cover	Front Output Group			
ZGAQ-02502	Ring-Retainer	Front Output Group			
ZGAQ-02504	Bolt-Wheel	Rear Output Group			
ZGAQ-02506	Ring-U	Front Brake Group			
ZGAQ-02507	Ring-Support	Front Brake Group			
ZGAQ-02508	Ring-U	Front Brake Group			
ZGAQ-02509	Ring-Support	Front Brake Group			
ZGAQ-02510	Ring-Guide	Front Brake Group			
ZGAQ-02563	Screw-Lock	Front Differential (Conventional)			
ZGAQ-02576	O-Ring	Rear Axle Casing Group			
ZGAQ-02577	Screw-Hex	Rear Axle Casing Group			
ZGAQ-02586	Gear-Planet	Rear Output Group			
ZGAQ-02591	Ring-U	Rear Brake Group			
ZGAQ-02592	Ring-U	Rear Brake Group			
ZGAQ-02594	Pin-Slot	Front Brake Group	#0001	-	
ZGAQ-02599	Pipe-Brake	Rear Axle Part Group			
ZGAQ-02621	Screw-Hex	Parking Brake (4-Speed)			
ZGAQ-02684	Washer	Front Axle Drive Housing			
ZGAQ-02690	Washer-Thrust	Front Differential (Conventional)			
ZGAQ-02701	Gear-Bevel	Front Differential (Conventional)			
ZGAQ-02702	Gear-Bevel	Front Differential (Conventional)			
ZGAQ-02711	Bearing-Taperroller	Front Output Group			
ZGAQ-02759	Screw-Hex	Front Axle Casing Group			
ZGAQ-02803	Plate-Seal	Gearshift System 3 (4-Speed)			
ZGAQ-02808	Plate-Seal	Gearshift System 1 (4-Speed)			
ZGAQ-02809	O-Ring	Pressure Oil Pump (4-Speed)			
ZGAQ-02855	Sheet-Screen	Parking Brake (4-Speed)			
ZGAQ-02856	Pump Assy-Gear	Pressure Oil Pump (4-Speed)			
ZGAQ-03557	Brake-Parking	Parking Brake (4-Speed)			
ZGAQ-03558	Seal Kit	Parking Brake (4-Speed)			
ZGAQ-03563	Repair Kit	Parking Brake (4-Speed)			
ZGAQ-03564	Lining Kit-Brake	Parking Brake (4-Speed)			
ZGAQ-03565	Repair Kit	Parking Brake (4-Speed)			
ZGAQ-03581	Plug-Screw	Front Axle Drive Housing	#0001	-	
ZGAQ-03746	Screw-Locking	Front Output Group			

ZGAQ-03771	Screw-Hex	Front Brake Group			
ZGAQ-03883	Shield-Protect	Front Input Group			
ZGAQ-03887	Washer-Thrust	Front Differential (Conventional)			
ZGAQ-03892	Bolt-Hex	Front Differential (Conventional)			
ZGAQ-03902	Bolt-Hex	Front Axle Casing Group			
ZGAQ-03903	O-Ring	Front Axle Casing Group			
ZGAQ-03906	Seal	Front Output Group			
ZGAQ-03910	Shaft-Gear	Front Output Group			
ZGAQ-03915	Washer	Front Brake Group			
ZGAQ-03916	Spring-Cup	Front Brake Group			
ZGAQ-03917	Cover	Front Brake Group	#0001	-	
ZGAQ-03940	Plug-Screw	Rear Axle Casing Group			
ZGAQ-03946	Shim-End	Rear Brake Group			
ZGAQ-04085	Bearing-Taperroller	Input Group (5-Speed)			
ZGAQ-04136	Bolt-Wheel	Front Output Group			
ZGAQ-04139	Shim-End	Front Brake Group			
ZGAQ-04143	Ring-Pressure	Front Differential Group (Limited Slip)			
ZGAQ-04390	Bolt-Stop	Front Output Group	#0001	-	
ZGAQ-04546	Bearing-Taperroller	Front Output Group			
ZGAQ-04589	Nut-Wheel	Front Loose Parts Group	#0001	-	
ZGAQ-04807	Screw-Sleeve	Rear Axle Part Group	#0001	-	
ZGAQ-04874	Piston	Front Brake Group	#0001	-	
ZGAQ-04903	Piston	Front Brake Group	#0001	-	
ZGAQ-04910	Bearing-Roller	Front Axle Drive Housing	#0001	-	
ZGAR-00620	Screw	Main Control Valve (2/2, 2-Spool)		-	#0381
ZGAR-00620	Screw			-	#0381
ZGAR-00629	Spring-Compression	Main Control Valve (2/2, 2-Spool)			
ZGAR-00630	Retainer-Spring	Main Control Valve (2/2, 2-Spool)		-	#0381
ZGAR-00630	Retainer-Spring			-	#0381
ZGAR-00676	Valve Assy-Relief/Press			-	#0381
ZGAR-00761	Screw-Cyl	Main Control Valve (2/2, 2-Spool)	#0382	-	
ZGAW-00008	Coil	Safety Valve			
ZGAW-00053	Filter-Line	Axle Oil Cooling Group 2 (Option)	#0108	-	
ZGAW-00056	Plug-Cavity	Ride Control Valve			
ZGBP-00320	Valve-Control	Fan & Brake Pump			