

HX220L

Part No	Part Name	Group Name	Start S/No		
			Start S/No	-	End S/No
11K6-21110	Element-A/C Outer	Side Cowl Assy (Lh, #1200-)	#1200	-	
11K6-21120	Element-A/C Inner	Side Cowl Assy (Lh, #1200-)	#1200	-	
11K6-90770	Filter-Aircon In	Aircon & Heater Unit (~#0831)		-	#0154
11K6-90780	Filter-Aircon In	Aircon & Heater Unit (~#0831)	#0831	-	#0831
11K6-91440	Filter-Inlet	Aircon & Heater Unit (#0832~)	#0832	-	
11K6-91451	Filter-Fresh	Aircon & Heater Group (#0832~)	#0832	-	
11KA-71040	Filter-Fuel	Fuel System			
11N6-27030	Element-A/C Inner	Side Cowl Assy (Lh, #0110-#1199)	#1199	-	#1199
11N6-27040	Element-A/C Outer	Side Cowl Assy (Lh, #0110-#1199)	#1199	-	#1199
11N6-90250	Belt-Aircon	Aircon & Heater Group (~#0831)	#0831	-	#0831
11N7-10010	Coupling Assy (11N7-10011)	Pump Mounting		-	#1246
11N7-10020	Element-Coupling	Pump Mounting			
11N7-10040	Insert-Coupling A	Pump Mounting		-	#1499
11N7-10050	Insert-Coupling R	Pump Mounting			
11N8-70110	Filter-Oil	Full Flow Oil Filter			
21K8-40101	Controller Assy-Jog Dial	Bottom Electric		-	#1322
21K8-41740	Arm Assy-Wiper	Cab Electric 1 (-#0232)	#0007	-	#0391
21K8-41741	Arm Assy-Wiper	Cab Electric 1 (-#0232)	#0232	-	#0232
21K8-41940	Arm Assy-Wiper	Cab Electric 1 (#0233-)	#0233	-	
21K8-41950	Blade Assy-Wiper	Cab Electric 1 (#0233-)	#0233	-	
21K8-44320	Arm Assy-Wiper	Electric 1 (-#1246)		-	#0067
21K8-44321	Arm-Wiper	Electric 1 (-#1246)	#1246	-	#1246
21M8-50310	Blade-Wiper	Electric 1 (-#1246)	#1246	-	#1246
21N8-20150	O-Ring	Fuse Box			
21Q6-01200	Arm&Blade Assy-Wiper	Cab Electric 1 (-#0232)		-	#0006
21Q6-01220	Arm-Wiper	Cab Electric 1 (-#0232)		-	#0006
21Q6-01230	Blade-Wiper	Cab Electric 1 (-#0232)		-	#0006
31K6-01310	Filter Assy-Drain	Hydraulic Tank	#0283	-	
31K6-01320	Filter-Drain	Hydraulic Tank	#0007	-	
31N4-01461	Element-Return	Hydraulic Tank		-	#0184
31N6-25070	Filter-Line	Single Acting Main Piping Kit (-#0004)	#0004	-	#0004
31N8-01350	Filter Assy-Drain	Hydraulic Tank		-	#0282
31N8-01360	Filter-Drain (31K6-01320)	Hydraulic Tank		-	#0006

31N8-13080	Hose-Rubber	Upper Hyd Piping (Base)	#0029	-	
31N8-13090	Hose-Rubber	Upper Hyd Piping (Base)		-	#0028
31Q6-20340	Filter-Line	Solenoid Valve			
31RF-10100	Element-Return (31RF-10350)	Hydraulic Tank	#0185	-	
31Y1-15696GG	Pipe Assy-Bs	Bucket Cylinder			
31Y1-29311GG	Pipe Assy-Rd	Bucket Cylinder			
32QA-00040	Breather Assy-Air	Hydraulic Tank			
3330202	O-Ring	Exhaust Recirculation			
33Q6-02600	Gauge-Level	Fuel Tank			
33Q6-02700	Gauge-Level	Hydraulic Tank			
3901448	Bolt	Exhaust Recirculation			
3968202	Cap-Filler	Valve Cover Arrangement			
5259499	Seal-Oil	Flywheel Housing			
5303743	Filter-Fuel	Fuel Filter Location			
61E3-12061	Pin-Joint	Bucket Control Group (Long Reach)			
61KH-72640	Bushing-Vhd	Bucket Control Group (Long Reach)			
61KH-73050	Bushing-Pin	Bucket Control Group			
61KH-82420	Bushing-Pin	Arm (6.3m, Long Reach)			
61KH-82630	Bushing-Pin	Arm (2.92m)			
61N4-11091	Pin-Joint	Bucket Control Group (Long Reach)			
61N6-11082	Pin-Joint	Bucket Control Group			
61N6-11112	Pin-Joint	Bucket Control Group			
61N6-30600	Bushing-Pin	Bucket (5 Teeth)			
61Q6-06500	O-Ring	Bucket Control Group		-	#1508
61Q6-06520	O-Ring	Bucket Control Group (Long Reach)			
61Q6-40050	Pin-Joint	Bucket Control Group			
61Q6-40060	Pin-Joint	Bucket Control Group			
61Q6-42060	Pin-Joint	Bucket Control Group (Long Reach)			
66N4-30350	Pin-Tooth	Bucket (0.52m3 Sae Heaped, Not Used)	#0001	-	#0001
71K8-02131	Latch Assy-Door	Cab Assy (5/5, Door)			
71K8-03300	Catch-Front	Cab Assy (5/5, Door)			
71K8-03310	Catch-Rear	Cab Assy (5/5, Door)			
71LM-00290	Filter-Aircon	Aircon & Heater Group (~#0831)	#0831	-	#0831
71N6-56400GG	Catch Assy	Cowling 1		-	#0606
71Q6-02481	Latch-Sliding Lh	Cab Assy (2/5, -#0006)	#0006	-	#0006
71Q6-02491	Latch-Sliding Rh	Cab Assy (2/5, -#0006)	#0006	-	#0006

71Q6-42400	Catch Assy	Tool Box		-	#0606
71Q6-42401	Catch Assy	Tool Box	#0607	-	
71Q6-52190	Latch Assy	Side Cover Assy (Lh)			
71Q6-52191	Latch Assy	Side Cover Assy (Lh)	#0607	-	
72Q6-02110	Handle-Outside	Cab Assy (5/5, Door)			
81N6-14111	Bar-Tie	Adjust Component (H/Walker, -#0088)	#0088	-	#0088
81N6-14120	Spring-Tension	Adjust Component (-#0520)	#0520	-	#0520
81N6-14210	Rod-Adjust	Adjust Component (-#0520)		-	#0282
81Q6-14242	Valve-Grease	Adjust Component (-#0520)	#0520	-	#0520
91N6-03133	Hose-H/Pressure	Decals (-#1246)	#1246	-	#1246
AF55308	Element-A/C Inner	Side Cowl Assy (Lh, -#0109)	#0109	-	#0109
E111-2504	Hose-Fuel	Cooling System	#0007	-	
E131-0214	Strainer-Suction	Hydraulic Tank			
E131-0594	Spring	Hydraulic Tank			
E161-3035	Pin-Tooth	Bucket (5 Teeth)			
E161-3035-S	Pin Set-Tooth	Bucket (5 Teeth)			
E262-5004	Pin-Tooth	Bucket (5 Teeth, Rock)			
E262-5004-S	Pin Set-Tooth	Bucket (5 Teeth, Rock)			
S611-019001	O-Ring	Rotating Main Piping Kit			
S611-023001	O-Ring	Rotating Main Piping Kit			
S621-012001	O-Ring	Upper Hyd Piping 2 (Boom Floating)			
S621-014001	O-Ring	Upper Hyd Piping (Travel)		-	#1246
S621-018001	O-Ring	Hydraulic Tank			
S621-018004	O-Ring	Travel Hyd Piping (T/Motor Type 1 & 2)			
S621-021001	O-Ring	Hydraulic Tank			
S621-025001	O-Ring	Single Acting Main Piping Kit (#0005-)	#0005	-	
S631-008004	O-Ring	Travel Motor (1/2, Type 1 & 2)			
S631-009004	O-Ring	Travel Motor (1/2, Type 1 & 2)			
S631-011001	O-Ring	Quick Clamp Piping			
S631-011004	O-Ring	Upper Hyd Piping 2 (Boom Floating)			
S631-012004	O-Ring	Swing Motor (Type 1 & 2)			
S631-014001	O-Ring	Quick Clamp Piping			
S631-014004	O-Ring	Pilot Hyd Piping (Base 1, #1247-)	#1247	-	
S631-015004	O-Ring	Travel Motor (1/2, Type 1 & 2)			
S631-018004	O-Ring	Fuel System			
S631-021001	O-Ring	Upper Hyd Piping 2 (Boom Floating)			

S631-021004	O-Ring	Travel Motor (1/2, Type 1 & 2)			
S631-024001	O-Ring	Travel Reduction Gear (Type 1 & 2)			
S631-024004	O-Ring	Upper Hyd Piping (Base)			
S631-029004	O-Ring	Hydraulic Tank			
S631-034004	O-Ring	Main Control Valve (3/4)			
S631-038004	O-Ring	Double Acting Main Piping Kit 1			
S631-071001	O-Ring	Upper Hyd Piping (Base)			
S631-120001	O-Ring	Swing Reduction Gear (Type 1 & 2)			
S631-12S004	O-Ring	Travel Motor (1/2, Type 1 & 2)			
S632-050004	O-Ring	Bucket Cylinder (Long Reach)			
S632-070001	O-Ring	Idler			
S632-075004	O-Ring	Arm Cylinder			
S632-095004	O-Ring	Bucket Cylinder (Long Reach)			
S632-100004	O-Ring	Adjust Cylinder			
S632-120004	O-Ring	Turning Joint			
S632-140004	O-Ring	Arm Cylinder			
S632-150001	O-Ring	Hydraulic Tank			
S632-170001	O-Ring	Fuel Tank			
S632-220001	O-Ring	Hydraulic Tank			
SP0100500	Sensor-Temp	Side Cowl Assy (Lh, -#0109)	#0109	-	#0109
X500-110001	Connector-Orfs	Upper Hyd Piping 2 (Boom Floating)			
XCAV-00026	O-Ring	Upper Hyd Piping (Base)		-	#0774
XCAV-00127	O-Ring	Boom Safety Lock System			
XJBN-00014	Valve Assy-Eppr	Main Pump (-#1246)	#1246	-	#1246
XJBN-00032	Plug	Main Pump (-#1246)	#1246	-	#1246
XJBN-00044	O-Ring	Regulator (-#1246)	#1246	-	#1246
XJBN-00045	O-Ring	Regulator (-#1246)	#1246	-	#1246
XJBN-00052	Ring-Snap	Main Pump (#1247-)	#1247	-	
XJBN-00083	Bushing-Spherical	Main Pump (-#1246)	#1246	-	#1246
XJBN-00084	Spring-Cyl	Main Pump (-#1246)	#1246	-	#1246
XJBN-00086	Support	Main Pump (-#1246)	#1246	-	#1246
XJBN-00090	Screw-Hex Socket	Main Pump (-#1246)	#1246	-	#1246
XJBN-00095	O-Ring	Main Pump (-#1246)	#1246	-	#1246
XJBN-00097	O-Ring	Regulator (-#1246)	#1246	-	#1246
XJBN-00099	Ring-Backup	Main Pump (-#1246)	#1246	-	#1246
XJBN-00100	Ring-Backup	Main Pump (-#1246)	#1246	-	#1246

XJBN-00102	Ring-Snap	Main Pump (-#1246)	#1246	-	#1246
XJBN-00103	Pin-Valve Plate	Main Pump (-#1246)	#1246	-	#1246
XJBN-00210	Screw-Socket	Regulator (#1247-)	#1247	-	
XJBN-00212	O-Ring	Main Control Valve (3/4)			
XJBN-00230	O-Ring	Regulator (-#1246)	#1246	-	#1246
XJBN-00231	O-Ring	Regulator (-#1246)	#1246	-	#1246
XJBN-00233	O-Ring	Main Pump (-#1246)	#1246	-	#1246
XJBN-00275	Ring-Snap	Regulator (-#1246)	#1246	-	#1246
XJBN-00279	O-Ring	Regulator (-#1246)	#1246	-	#1246
XJBN-00280	O-Ring	Regulator (-#1246)	#1246	-	#1246
XJBN-00281	O-Ring	Regulator (-#1246)	#1246	-	#1246
XJBN-00282	O-Ring	Regulator (-#1246)	#1246	-	#1246
XJBN-00283	O-Ring	Gear Pump (-#1246)	#1246	-	#1246
XJBN-00285	O-Ring	Regulator (-#1246)	#1246	-	#1246
XJBN-00318	Screw	Regulator (-#1246)	#1246	-	#1246
XJBN-00325	O-Ring	Gear Pump (-#1246)	#1246	-	#1246
XJBN-00355	Bolt-Socket	Main Pump (-#1246)	#1246	-	#1246
XJBN-00361	O-Ring	Main Pump (-#1246)	#1246	-	#1246
XJBN-00362	O-Ring	Main Pump (-#1246)	#1246	-	#1246
XJBN-00363	O-Ring	Main Pump (-#1246)	#1246	-	#1246
XJBN-00382	Valve Assy-Eppr	Eppr Valve (-#1246)	#1246	-	#1246
XJBN-00541	Spring-Cyl	Main Pump (#1247-)	#1247	-	
XJBN-00546	O-Ring	Eppr Valve (-#1246)	#1246	-	#1246
XJBN-00547	O-Ring	Eppr Valve (-#1246)	#1246	-	#1246
XJBN-00548	O-Ring	Eppr Valve (-#1246)	#1246	-	#1246
XJBN-00820	O-Ring	Regulator (-#1246)	#1246	-	#1246
XJBN-00864	Ring-Backup	Main Pump (#1247-)	#1247	-	
XJBN-00865	Ring-Backup	Main Pump (#1247-)	#1247	-	
XJBN-00903	O-Ring	Regulator (#1247-)	#1247	-	
XJBN-01026	O-Ring	Regulator (-#1246)	#1246	-	#1246
XJBN-01172	O-Ring	Main Pump (#1247-)	#1247	-	
XJBN-01221	O-Ring	Main Control Valve (3/4)			
XJBN-01222	O-Ring	Main Control Valve (3/4)			
XJBN-01234	O-Ring	Main Control Valve (1/4)			
XJBN-01357	O-Ring	Main Control Valve (1/4)			
XJBN-01358	O-Ring	Main Control Valve (3/4)			

XJBN-01366	O-Ring	Main Control Valve (1/4)			
XJBN-01815	Plug	Remote Control Lever (Type M11, #0748-)	#0748	-	
XJBN-01817	Seal-Oil	Remote Control Lever (Type M11, #0748-)	#0748	-	
XJBN-01820	Seat-Spring	Remote Control Lever (Type M11, #0748-)	#0748	-	
XJDB-00032	O-Ring	Control Valve (Adjust Boom)			
XJDB-00309	Chip-Nylon	Control Valve (Adjust Boom)			
XKAL-00050	Coil	Double Acting Main Piping Kit 2			
XKAL-00090	Coil	Quick Clamp Piping		-	#0802
XKAL-00119	Coil	Double Acting Main Piping Kit 2			
XKAL-00125	Coil	One Pedal Straight Solenoid Valve			
XKAL-00135	O-Ring Kit	Double Acting Main Piping Kit 2			
XKAN-01087	O-Ring	Air Conditioner Bottom Sub		-	#0831
XKAN-01088	O-Ring	Aircon & Heater Group (-#0831)	#0831	-	#0831
XKAN-01090	O-Ring	Air Conditioner Bottom Sub		-	#0831
XKAY-00005	Bellows	Single Pedal (Double Acting)			
XKAY-00007	Screw-Set	Single Pedal (Double Acting)			
XKAY-00009	Shaft-Cam	Single Pedal (Double Acting)			
XKAY-00010	Bushing	Single Pedal (Double Acting)			
XKAY-00011	Cam	Remote Control Pedal (-#0350)	#0350	-	#0350
XKAY-00017	Plug	Remote Control Pedal (-#0350)	#0350	-	#0350
XKAY-00021	Seal	Remote Control Pedal (-#0350)	#0350	-	#0350
XKAY-00049	Joint Assy	Remote Control Lever (Type M1, -#0747)	#0747	-	#0747
XKAY-00052	Rod-Push	Remote Control Lever (Type M1, -#0747)	#0747	-	#0747
XKAY-00055	Seal-Oil	Single Pedal (Double Acting)			
XKAY-00058	Stopper	Single Pedal (Double Acting)			
XKAY-00067	Seal-Oil	Remote Control Pedal (-#0350)	#0350	-	#0350
XKAY-00323	O-Ring	Remote Control Pedal (-#0350)	#0350	-	#0350
XKAY-00438	O-Ring	Single Pedal (Double Acting)			
XKAY-00559	Plug	Single Pedal (Double Acting)			
XKAY-00665	O-Ring	Remote Control Pedal (-#0350)	#0350	-	#0350
XKAY-00786	Boot	Remote Control Lever (Type M1, -#0747)	#0747	-	#0747
XKAY-01060	Rod-Push	Single Pedal (Double Acting)			
XKAY-01714	Plug	Remote Control Lever (Type M1, -#0747)	#0747	-	#0747
XKAY-01718	Handle Assy-Lh	Remote Control Lever (Type M1, -#0747)	#0747	-	#0747
XKAY-01719	Handle Assy-Rh	Remote Control Lever (Type M1, -#0747)	#0747	-	#0747
XKBL-00134	Coil-Solenoid	Solenoid Valve			

XKBN-00015	O-Ring	Breaker Assy (1/3)			
XKBN-00127	O-Ring	Breaker Assy (1/3)			
XKBN-00181	O-Ring	Breaker Assy (1/3)			
XKBN-00539	O-Ring	Breaker Assy (1/3)			
XKBN-00876	O-Ring	Breaker Assy (1/3)			
XKBN-00877	O-Ring	Breaker Assy (1/3)			
XKBN-00908	O-Ring	Breaker Assy (2/3)			
XKCC-00051	O-Ring	Bucket Cylinder(Long Reach,Shpac,#0641-)	#0641	-	
XKCC-00063	O-Ring	Bucket Cylinder(Long Reach,Shpac,#0641-)	#0641	-	
XKCC-00139	O-Ring	Bucket Cylinder(Long Reach,Shpac,#0641-)	#0641	-	
XKCC-00896	O-Ring	Boom Cylinder(Shpac,#0641-)	#0641	-	
XKCF-00007	Plug	Lower Roller			
XKCF-01005	O-Ring	Lower Roller			
XKCH-00294	Coil-Solenoid	Solenoid Valve			
XKDB-00032	O-Ring	Remote Control Lever (Type M1, -#0747)	#0747	-	#0747
XKDB-00037	Plug Assy	Remote Control Lever (Type M2, -#0747)	#0747	-	#0747
XKDE-00134	Washer-Seal	Fuel Drain Plumbing			
XKDE-00316	Sensor-Position	Engine Control Module			
XKDE-00322	Screw-Hex Flg	Crankcase Breather			
XKDE-00324	Screw-Hex Flg	Rear Gear Housing			
XKDE-00332	Sensor-Temp	Engine Control Module			
XKDE-00359	O-Ring	Injector			
XKDE-00417	Retainer	Injector Plumbing			
XKDE-00460	Spacer-Mount	Exhaust Recirculation			
XKDE-00478	O-Ring	Turbocharger Mounting			
XKDE-00479	O-Ring	Turbocharger Mounting			
XKDE-00526	Screw-Hex Flg	Exhaust Recirculation Water Plumbing			
XKDE-00630	Screw-Hex Flg	Flywheel Housing			
XKDE-01341	Retainer	Cylinder Head			
XKDE-01374	Screw-Hex Flg	Flywheel Housing			
XKDE-01377	Screw-Hex Flg	Air Intake Manifold			
XKDE-01416	O-Ring	Engine Control Module			
XKDE-01418	O-Ring	Turbocharger Plumbing			
XKDE-01431	Seal	Thermostat			
XKDE-01489	Sensor-Pressure	Engine Control Module			
XKDE-01495	Thermostat	Thermostat			

XKDE-02110	Insert-Valve	Cylinder Head			
XKDE-02113	Insert-Valve	Cylinder Head			
XKDE-02119	Washer-Seal	Turbocharger Mounting			
XKDE-02123	Washer-Seal	Exhaust Recirculation			
XKDE-02204	Belt-Fan	Water Pump Drive			
XKDR-00054	O-Ring	Upper Hyd Piping 2 (Boom Floating)			
Y171-015004	O-Ring	Bucket Cylinder (Long Reach)			
Y171-019004	O-Ring	Upper Hyd Piping (Attach)			
Y172-003004	O-Ring	Cooling System		-	#0792
Y172-006004	O-Ring	Upper Hyd Piping (Base)		-	#0774
Y172-041004	O-Ring	Swing Motor (Type 1 & 2)			
Y172-042004	O-Ring	Swing Motor (Type 1 & 2)	#0001	-	
Y172-043004	O-Ring	Swing Motor (Type 1 & 2)			
YUBP-00025	Seal-Oil	Flywheel Housing			
YUBP-00197	Screw-Hex Flg	Fuel Filter Location			
YUBP-01171	Valve Kit-Intake	Cylinder Head			
YUBP-02483	Sensor-Temp	Engine Control Module			
YUBP-02593	Washer-Seal	Fuel Drain Plumbing			
YUBP-02628	Bolt-Hex	Flywheel Mounting			
YUBP-04084	Ring-Retainer	Fan Drive			
YUBP-04280	O-Ring	Exhaust Recirculation Water Plumbing			
YUBP-07227	Seal	Water Pump			
YUBP-10389	Sensor-Nitrogen	Aftertreatment Device			
YUBP-10806	Element-Breather	Crankcase Breather			
YUBP-11420	Tensioner Assy-Belt	Belt Tensioner			
YUBP-11638	Screen	Fuel Filter Location			
YUBP-11780	Seal	Injector			
YUBP-11900	Injector-Reactor	Aftertreatment Device			